

PLATING SPECIFICATIONS

Body: G - Gold N - Nickel S - Silver SS - Stainless Steel **Pin/Contact:** G - Gold **Dielectric:** T- PTFE



FIG. 1
RFB-1142, -4, -5, -6



FIG. 2
RFE-6110



FIG. 3
RFE-6111



FIG. 4
RFT-1241-4



FIG. 5
RFT-1241-5



FIG. 6
RFT-1241-6



FIG. 7
RFU-642



FIG. 8
RSA-3290, -10




FIG. 9
RSA-3400, -1



FIG. 10
RSA-3401



FIG. 11
RSA-3402, -1



FIG. 12
RSA-3403, -1

PHOTOS FOR REFERENCE ONLY, SHOWN AT 100% ACTUAL SIZE.

| PART # | FIG | DESCRIPTION | NOTES | REPLACES OR EQUIVALENT TO | PLATING | | |
|-----------------------------|-----|----------------------------|--------------------------------------------------------|----------------------------|---------|-----|-----|
| | | | | | BDY | P/C | DIE |
| RFB-1142 | 1 | Adapter | BNC Female to SMA Female | UNIDEN / Johnson SMR | N | G | T |
| RFB-1142-4 | 1 | Adapter | BNC Female to SMA (Motorola) Female | Use with Motorola Cellular | N | G | T |
| RFB-1142-5 | 1 | Adapter | BNC Female to SMA Female (OKI 900) | Use with OKI 900 Cellular | N | G | T |
| RFB-1142-6 | 1 | Adapter | BNC Female to SMA (Motorola) Female Q/D* | *1.5 Turns | N | G | T |
| RFE-6110 | 2 | Adapter | FME Male to SMA Female | | N | G | T |
| RFE-6111 | 3 | Adapter | FME Male to SMA Male | | N | G | T |
| RFT-1241-4 | 4 | Adapter | TNC Female to SMA (Motorola) Female | use with Motorola Cellular | N | G | T |
| RFT-1241-5 | 5 | Adapter | TNC Female to SMA (OKI 900) Female | use with OKI 900 Cellular | N | G | T |
| RFT-1241-6 | 6 | Adapter | TNC Female to SMA Male | | N | G | T |
| RFU-642 | 7 | Adapter | Mini UHF Female to SMA (Motorola) Female | for Motorola Cellular | N | G | T |
| RSA-3290 | 8 | Female Panel Mount Adapter | 4 Hole Flange, SMA Female to N Female, Stainless Steel | | SS | G | T |
| RSA-3290-10 | 8 | Female Panel Mount Adapter | 4 Hole Flange, SMA Female to N Female | | N | G | T |
| RSA-3400 | 9 | T-Adapter | SMA Male to Double SMA Female | | N | G | T |
| RSA-3400-1 | 9 | T-Adapter | SMA Male to Double SMA Female | | G | G | T |
| RSA-3401 | 10 | T-Adapter | SMA Triple Female | | N | G | T |
| RSA-3402 | 11 | Right Angle Adapter | SMA Male to SMA Female | | N | G | T |
| RSA-3402-1 | 11 | Right Angle Adapter | SMA Male to SMA Female | | G | G | T |
| RSA-3403 | 12 | Adapter | SMA Male to SMA Male | | N | G | T |
| RSA-3403-1 | 12 | Adapter | SMA Male to SMA Male | | G | G | T |

SMA ADAPTERS

SMA



FIG. 13
RSA-3404



FIG. 14
RSA-3405, -1



FIG. 15
RSA-3406



FIG. 16
RSA-3407-1



FIG. 17
RSA-3407-4-03, -4-LF



FIG. 18
RSA-3408-1



FIG. 19
RMC-6021



FIG. 20
RSA-3410, -1



FIG. 21
RSA-3413



FIG. 22
RSA-3413-3



FIG. 23
RSA-3450



FIG. 24
RSA-3451



FIG. 25
RSA-3452



FIG. 26
RSA-3453



FIG. 27
RSA-3454



FIG. 28
RSA-3456

PHOTOS FOR REFERENCE ONLY, SHOWN AT 100% ACTUAL SIZE.

| PART # | FIG | DESCRIPTION | NOTES | REPLACES OR EQUIVALENT TO | PLATING | | |
|-------------------------------|-----|---------------------|--------------------------------------------------|---------------------------|---------|-----|-----|
| | | | | | BDY | P/C | DIE |
| RSA-3404 | 13 | Adapter | SMA Female to SMA Female | | N | G | T |
| RSA-3405 | 14 | Adapter | SMA Male to SMA Female | | N | G | T |
| RSA-3405-1 | 14 | Adapter | SMA Male to SMA Female | | G | G | T |
| RSA-3406 | 15 | Adapter | SMA Female to SMB Jack | | N | G | T |
| RSA-3407-1 | 16 | Adapter | SMA Female to Nokia Male | | G | G | T |
| RSA-3407-4-03 | 17 | Right Angle Adapter | SMA Female to DTC4 Nokia | | G | G | T |
| RSA-3407-4-LF | 17 | Right Angle Adapter | SMA Female to DTC4 Nokia (Easy-snap) | | G | G | T |
| RSA-3408-1 | 18 | Adapter | SMA Female to MMCX Plug | | G | G | T |
| RMC-6021 | 19 | Adapter | MC Card Plug to SMA female | | N | G | T |
| RSA-3410 | 20 | Bulkhead Adapter | SMA Female to SMA Female with D-Flat | | N | G | T |
| RSA-3410-1 | 20 | Bulkhead Adapter | SMA Female to SMA Female with D-Flat | | G | G | T |
| RSA-3413 | 21 | Bulkhead Adapter | SMA Female to BNC Female | | N | G | T |
| RSA-3413-3 | 22 | Bulkhead Adapter | SMA Female to BNC Female, w/ .375-32UNEF Threads | | N | G | T |
| RSA-3450 | 23 | Adapter | SMA Male to Mini UHF Female | | N | G | T |
| RSA-3451 | 24 | Adapter | SMA Male to Mini UHF Male | | N | G | T |
| RSA-3452 | 25 | Adapter | SMA Male to N Female | | N | G | T |
| RSA-3453 | 26 | Adapter | SMA Male to N Male | | N | G | T |
| RSA-3454 | 27 | Adapter | SMA Male to TNC Male | | N | G | T |
| RSA-3456 | 28 | Adapter | SMA Male to UHF Male | | N | G | T |

SMA ADAPTERS



FIG. 29
RSA-3457



FIG. 30
RSA-3458



FIG. 31
RSA-3459



FIG. 32
RSA-3470



FIG. 33
RSA-3471



FIG. 34
RSA-3472



FIG. 35
RSA-3473



FIG. 36
RSA-3474



FIG. 37
RSA-3475



FIG. 38
RSA-3476, -1



FIG. 39
RSA-3477, -2



FIG. 40
RSA-3477-03



FIG. 41
RSA-3478



FIG. 42
RSA-3494

PHOTOS FOR REFERENCE ONLY, SHOWN AT 100% ACTUAL SIZE.

| PART # | FIG | DESCRIPTION | NOTES | REPLACES OR EQUIVALENT TO | PLATING | | |
|-----------------------------|-----|------------------|-----------------------------------------------------------------|---------------------------|---------|-----|-----|
| | | | | | BDY | P/C | DIE |
| RSA-3457 | 29 | Adapter | SMA Male to UHF Female | | N | G | T |
| RSA-3458 | 30 | Adapter | SMA Male to BNC Female | | N | G | T |
| RSA-3459 | 31 | Adapter | SMA Male to BNC Male | | N | G | T |
| RSA-3470 | 32 | Adapter | SMA Female to Mini UHF Male | | N | G | T |
| RSA-3471 | 33 | Adapter | SMA Female to Mini UHF Female | | N | G | T |
| RSA-3472 | 34 | Adapter | SMA Female to TNC Male | | N | G | T |
| RSA-3473 | 35 | Adapter | SMA Female to TNC Female | | N | G | T |
| RSA-3474 | 36 | Adapter | SMA Female to UHF Male | | N | G | T |
| RSA-3475 | 37 | Adapter | SMA Female to UHF Female | | N | G | T |
| RSA-3476 | 38 | Adapter | SMA Female to BNC Male | | N | G | T |
| RSA-3476-1 | 38 | Adapter | SMA Female to BNC Male | | G | G | T |
| RSA-3477 | 39 | Adapter | SMA FEMALE TO N FEMALE | | N | G | T |
| RSA-3477-03 | 40 | Bulkhead Adapter | SMA Female to N Female Feed Through with Gasket & Double D-Flat | | N | G | T |
| RSA-3477-2 | 39 | Adapter | SMA Female to N Female | | S | G | T |
| RSA-3478 | 41 | Adapter | SMA Female to N Male | | N | G | T |
| RSA-3494 | 42 | Adapter | SMA Male to MHF Jack | | G | G | T |