



FIG. 59  
RFN-1028-I2, -PL, -SI, SI2



FIG. 60  
RFN-1029-SP, -SX



FIG. 61  
RFN-1034-1




FIG. 62  
RFN-1035-1



FIG. 63  
RFN-1036-1



FIG. 64  
RFN-1037-1



FIG. 65  
RFN-1038-1



FIG. 66  
RFN-1039-1



FIG. 67  
RFN-1040-1



FIG. 68  
RFN-1041-1



FIG. 69  
RFN-1054-AV



FIG. 70  
RFS-2030

PHOTOS FOR REFERENCE ONLY, SHOWN AT 75% ACTUAL SIZE.

FOR MOUNTING CONFIGURATIONS

PART #	FIG	DESCRIPTION	CBL GRP	NOTES	REPLACES OR EQUIVALENT TO	PLATING			RECOM-MENDED TOOL
						BDY	P/C	DIE	
<a href="#">RFN-1028-PL</a>	59	Female Crimp	PL	for Belden 89913 Plenum		S	G	T	<a href="#">RFA-4005-200</a>
<a href="#">RFN-1028-SI</a>	59	Female Crimp	I	for Belden 9913 & Times LMR-400		S	G	T	<a href="#">RFA-4005-200</a>
<a href="#">RFN-1028-SI2</a>	59	Female Crimp	I2	for LMR-400LLPL		S	G	T	
<a href="#">RFN-1029-SP</a>	60	Female Crimp	P	for Proflex		S	G	T	<a href="#">RFA-4009-203</a>
<a href="#">RFN-1029-SX</a>	60	Female Crimp	X	for RG-8/X & Times LMR-240		S	G	T	<a href="#">RFA-4009-203</a>
<a href="#">RFN-1034-1</a>	61	<a href="#">Female Adapter</a>		N Female to UHF Female		S	G	T	
<a href="#">RFN-1035-1</a>	62	<a href="#">Male Adapter</a>		N Male to UHF Female		S	G	T	
<a href="#">RFN-1036-1</a>	63	<a href="#">Female Adapter</a>		N Female to UHF Male		S	G	T	
<a href="#">RFN-1037-1</a>	64	<a href="#">Male Adapter</a>		N Male to BNC Female		S	G	T	
<a href="#">RFN-1038-1</a>	65	<a href="#">Female Adapter</a>		N Female to BNC Male		S	G	T	
<a href="#">RFN-1039-1</a>	66	<a href="#">Female Adapter</a>		N Female to BNC Female		S	G	T	
<a href="#">RFN-1040-1</a>	67	<a href="#">Male Adapter</a>		N Male to BNC Male		S	G	T	
<a href="#">RFN-1041-1</a>	68	Male Panel Mount		4 Hole Flange, Soldercup		S	G	T	
<a href="#">RFN-1054-AV</a>	69	<a href="#">Right Angle Adapter</a>		N Male to N Male		N	G	T	
<a href="#">RFS-2030</a>	70	N Female Bulkhead Vertical PCB Mount		Double D Flat, 1.645" Threads		N	S	T	