

M/A-Com/TYCO & RF Connectors

Cross Reference

Connector to Connector Cross Reference



The information found in this guide was compiled using specifications that were current at the time of compilation. Please note that manufacturer's specifications are subject to change without notice. We therefore suggest that after using this guide to make your initial connector selections, you should obtain the latest product specifications from this cable manufacturer and RF Industries.

RF Connectors, Division of RF Industries, 7610 Miramar Road, San Diego, CA 92126-4202
For product information call (800) 233-1728 or (858) 549-6340, Fax: (858) 549-6345
E-mail: rfi@rfindustries.com Web: www.rfindustries.com www.rfcoaxconnectors.com





CROSS REFERENCE

M/A-COM/TYCO TO RF CONNECTORS

MA/COM P/N	RFI P/N	Description	Notes	
3333	RSA-3477-03	SMA FEM TO N FEM FEED THROUGH W/GASKET & DBL D FLAT BULKHEAD ADAPTER, N,G,T		
35028	RFB-1132	BNC MALE TO BNC FEM R/A ADAPTER, N,S,T		
35031	RFB-1130	BNC T ADAPTER 2 FEM-1 MALE, N,G,T		
35032	RFB-1133	BNC MALE TO BNC MALE ADAPTER, N,S,T		
35034	RFB-1134	BNC FEM TO BNC FEM BARREL ADAPTER, N,S,D		
35076	RFB-1143	BNC MALE BLKHD PLUG, FRONT MNT, D-FLAT, N,G,T		
35262	RFB-1115-4	BNC FEM VERT PCB MNT, 4 LEGS , S,G,T		
35282	RFB-1113-B-04	BNC FEM R/A HI-PROFILE PCB MNT, (BLACK), A-G-P; POST LEG;W/ NO HARDWARE		
35283	RFB-1112-1B-04	BNC FEM VERT LOW-PROFILE PCB MNT,(BLACK), A,G,P; POST LEG; W/ NO HARDWARE		
35287	RFB-1135	BNC FEM TO BNC FEM BLKHD ADAPTER, N,G,D		
35288	RFB-1135	BNC FEM TO BNC FEM BLKHD ADAPTER, N,G,D		
35288	RFB-1135-T	BNC FEM TO BNC FEM BLKHD ADAPTER, O-RING, N,S,T		
37166	RFB-1116	BNC FEM DIECAST BLKHD, SOLDER CUP, N,G,D		
37166	RFB-1116-NG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, N,G,T		
37166	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D		
37527	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D		
37596	RFB-1131	BNC T ADAPTER, TRIPLE BNC FEM, N,S,T		
50007	RFB-1137	BNC FEM TO UHF MALE ADAPTER, N,S,D		
50008	RFB-1136	BNC MALE TO UHF FEM ADAPTER, N,S,D		
50028	RFB-1132	BNC MALE TO BNC FEM R/A ADAPTER, N,S,T		
1501A10	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
2001-5003-02	RSA-3500-1-141	SMA MALE STRAIGHT PLUG, G,G,T; FOR .141 SEMI-RIGID, CBL GRP SR2	N34	
2001-5003-02	RSA-3500-141	SMA, MALE STRAIGHT PLUG, N,G,T; FOR SEMI-RIGID .141, CBL GRP SR2	N10	
2001-5009-02	RSA-3500-085	SMA, MALE STRAIGHT CABLE PLUG, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N32	
2001-5009-02	RSA-3500-1-085	SMA MALE STRAIGHT PLUG, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N34	
2001-5032-02	RSA-3500-085	SMA, MALE STRAIGHT CABLE PLUG, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N32	
2001-5032-02	RSA-3500-1-085	SMA MALE STRAIGHT PLUG, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N34	
2001-5119-02	RSA-3500-085	SMA, MALE STRAIGHT CABLE PLUG, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N34	N62
2001-5119-02	RSA-3500-1-085	SMA MALE STRAIGHT PLUG, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N34	N62
2001-7141-12	RSA-3100-C	SMA, MALE SOLDER CLAMP, N,G,T; FOR RG-58/U, RG-142/U & RG-55/U, CBL GRP C,C1	N39	N57
2001-7188-02	RSA-3100-B	SMA, MALE SOLDER CLAMP, N,G,T; FOR RG-174/U, RG-316/U & RG-316 DBL SHIELD, CBL GRP B,B1	N39	N57
2001-7585-02	RSA-3500-085	SMA, MALE STRAIGHT CABLE PLUG, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N32	N57
2001-7585-02	RSA-3500-1-085	SMA MALE STRAIGHT PLUG, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N34	N57
2001-7841-02	RSA-3510-1-085	SMA, MALE R/A PLUG, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N39	N62
2001-7885-02	RSA-3500-085	SMA, MALE STRAIGHT CABLE PLUG, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N39	N62
2001-7885-02	RSA-3500-1-085	SMA MALE STRAIGHT PLUG, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1		
2001-7943-02	RSA-3500-1-141	SMA MALE STRAIGHT PLUG, G,G,T; FOR .141 SEMI-RIGID, CBL GRP SR2	N34	N62
2001-7943-02	RSA-3500-141	SMA, MALE STRAIGHT PLUG, N,G,T; FOR SEMI-RIGID .141, CBL GRP SR2	N32	N62
2001-7985-02	RSA-3510-1-085	SMA, MALE R/A PLUG, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N34	
2001-7985-02	RSA-3500-085	SMA, MALE STRAIGHT CABLE PLUG, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N32	
2001-7985-02	RSA-3500-1-085	SMA MALE STRAIGHT PLUG, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N34	
2002-5012-00	RSA-3555-SR2	SMA, FEM, N,G,T; FOR .141 SEMI-RIGID, CBL GRP SR2	N36	N62
2002-5016-00	RSA-3555-SR1	SMA, FEM, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N32	N62
2002-7541-00	RSA-3555-SR2	SMA, FEM, N,G,T; FOR .141 SEMI-RIGID, CBL GRP SR2	N32	N57
2002-7585-00	RSA-3555-SR1	SMA, FEM, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N32	N57
2002-7841-02	RSA-3555-SR2	SMA, FEM, N,G,T; FOR .141 SEMI-RIGID, CBL GRP SR2	N39	N62
2002-7885-02	RSA-3555-SR1	SMA, FEM, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N39	N62
2004-7541-00	RSA-3560-141	SMA, FEM BLKHD, N,G,T; FOR SEMI-RIGID CBL.141, CBL GRP SR2	N57	
2004-7585-00	RSA-3560-1-SR1	SMA, FEM BLKHD, REAR MNT, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N57	
2004-7841-02	RSA-3560-141	SMA, FEM BLKHD, N,G,T; FOR SEMI-RIGID CBL.141, CBL GRP SR2	N39	N57
2004-7885-02	RSA-3560-1-SR1	SMA, FEM BLKHD, REAR MNT, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N35	

2004-7941-00	RSA-3560-141	SMA, FEM BLKHD, N,G,T; FOR SEMI-RIGID CBL.141, CBL GRP SR2	N12	
2004-7985-00	RSA-3560-1-SR1	SMA, FEM BLKHD, REAR MNT, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1		
2006-5010-00	RSA-3550-085	SMA, FEM 2-HOLE PANEL MNT, N,G,T; FOR .085 SEMI-RIGID CABLE, CBL GRP SR1	N12	
2006-5010-00	RSA-3550-1-085	SMA, FEM 2-HOLE PANEL MNT, G,G,T; FOR .085 SEMI-RIGID CABLE, CBL GRP SR1		
2006-5012-00	RSA-3570-085	SMA FEM 4-HOLE PANEL MNT, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N12	
2006-5084-02	RSA-3570-085	SMA FEM 4-HOLE PANEL MNT, N,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N39	N62
2007-5054-02	RSA-3510-1-141	SMA, MALE R/A PLUG, G,G,T; FOR .141 SEMI-RIGID, CBL GRP SR2	N34	
2007-5054-02	RSA-3510-141	SMA, MALE R/A PLUG, N,G,T; FOR .141 SEMI-RIGID, CBL GRP SR1	N34	
2007-5055-02	RSA-3510-085	SMA, MALE R/A PLUG, N,G,T; FOR .085 SEMI-RIGID CBL, GRP SR1	N37	
2007-5055-02	RSA-3510-1-085	SMA, MALE R/A PLUG, G,G,T; FOR .085 SEMI-RIGID, CBL GRP SR1	N34	
2007-7141-02	RSA-3110-C	SMA, MALE R/A SOLDER CLAMP, N,G,T; FOR RG-58/U, RG-142/U & RG-55/U, CBL GRP C,C1	N39	N57
2007-7188-02	RSA-3110-B	SMA, MALE R/A SOLDER CLAMP, N,G,T; FOR RG-174/U, RG-316/U & RG-316 DBL SHIELD, CBL GRP B,B1	N39	N57
2007-7941-02	RSA-3510-1-141	SMA, MALE R/A PLUG, G,G,T; FOR .141 SEMI-RIGID, CBL GRP SR2	N34	
2007-7941-02	RSA-3510-141	SMA, MALE R/A PLUG, N,G,T; FOR .141 SEMI-RIGID, CBL GRP SR1	N37	
2007-7985-02	RSA-3510-085	SMA, MALE R/A PLUG, N,G,T; FOR .085 SEMI-RIGID CBL, GRP SR1	N37	
2031-5002-02	RSA-3000-C	SMA, MALE CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N10	
2031-5003-02	RSA-3000-B	SMA, MALE 3 PIECE CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N10	
2031-5005-02	RSA-3000-1C	SMA, MALE 3 PIECE CRIMP, G,G,T; FOR RG-58/U, CBL GRP C	N35	
2031-5005-02	RSA-3000-C	SMA, MALE CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N39	
2031-5005-02	RSA-3000-C1	SMA, MALE CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N39	N57
2031-5006-02	RSA-3000-1B	SMA, MALE 3 PIECE CRIMP, G,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N35	
2031-5006-02	RSA-3000-B	SMA, MALE 3 PIECE CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N39	
2031-5011-02	RSA-3000-C1	SMA, MALE CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N39	N57
2031-5012-02	RSA-3000-1B	SMA, MALE 3 PIECE CRIMP, G,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N35	N57
2031-5012-02	RSA-3000-B	SMA, MALE 3 PIECE CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N39	N57
2031-5056-02	RSA-3000-1C	SMA, MALE 3 PIECE CRIMP, G,G,T; FOR RG-58/U, CBL GRP C	N35	N57
2031-5056-02	RSA-3000-C	SMA, MALE CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N39	N57
2031-5102-02	RSA-3000-A	SMA, MALE 3 PIECE CRIMP, N,G,T; FOR RG-178/U, CBL GRP A	N39	N57
2032-5003-02	RSA-3050-B	SMA, FEM STRAIGHT CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N39	N57
2032-5007-02	RSA-3050-C1	SMA, FEM CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1,	N39	N57
2032-5021-02	RSA-3050-C	SMA, FEM CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N39	N57
2034-5004-02	RSA-3252-C1	SMA, FEM BLKHD CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N39	N57
2034-5005-02	RSA-3252-B	SMA, FEM BLKHD, W/O GASKET, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N39	N57
2034-5005-02	RSA-3252-B-03	SMA, FEM BLKHD, W/ GASKET, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N39	N57
2034-5023-02	RSA-3252-C	SMA, FEM BLKHD CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N39	N57
2036-5014-02	RSA-3260-C*	SMA, FEM CRIMP 2-HOLE FLANGE PANEL MNT, RG-58/U, N,G,T	N39	N57
2037-5005-02	RSA-3010-C	SMA, MALE R/A CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N10	
2037-5007-02	RSA-3010-C1	SMA, MALE R/A CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N39	N57
2037-5008-02	RSA-3010-B	SMA, MALE R/A CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N39	N57
2037-5056-02	RSA-3010-C	SMA, MALE R/A CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N39	N57
2037-5100-02	RSA-3010-A*	SMA, MALE R/A CRIMP, RG-178/U, N,G,T	N39	N57
2051-0000-02	RSA-3231	SMA, MALE BLKHD,4-HOLE PANEL MNT, SOLDER CUP, N,G,T	N39	N57
2051-0000-02	RSA-3231-1	SMA, MALE BLKHD, 4-HOLE PANEL MNT, SOLDER CUP, G,G,T	N39	N57
2051-1350-02	RSA-3221	SMA, MALE BLKHD,2-HOLE PANEL MNT, SOLDER CUP, N,G,T	N39	N57
2051-1351-02	RSA-3268	SMA, FEM 2-HOLE PANEL MNT, .196 EXTENDED DIELECTIC, POST TERMINAL, N,G,T	N39	
2051-1352-02	RSA-3268	SMA, FEM 2-HOLE PANEL MNT, .196 EXTENDED DIELECTIC, POST TERMINAL, N,G,T	N39	N57
2051-1900-02	RSA-3231	SMA, MALE BLKHD,4-HOLE PANEL MNT, SOLDER CUP, N,G,T	N39	N57
2051-1900-02	RSA-3231-1	SMA, MALE BLKHD, 4-HOLE PANEL MNT, SOLDER CUP, G,G,T	N39	N57
2052-0000-02	RSA-3271	SMA, FEM 4-HOLE PANEL MNT, SOLDER CUP, N,G,T	N10	
2052-1200-02	RSA-3279	SMA, FEM 4-HOLE PANEL MNT, .590" EXTENDED DIELECTRIC, N,G,T	N39	
2052-1201-02	RSA-3279	SMA, FEM 4-HOLE PANEL MNT, .590" EXTENDED DIELECTRIC, N,G,T	N39	N57
2052-1300-02	RSA-3261	SMA, FEM 2-HOLE PANEL MNT, SOLDER CUP, CBL GRP C, N,G,T	N39	N57
2052-1350-02	RSA-3261	SMA, FEM 2-HOLE PANEL MNT, SOLDER CUP, N,G,T; FOR RG-58/U, CBL GRP C	N39	N57
2052-1351-02	RSA-3269	SMA, FEM 2-HOLE PANEL MNT, .590" EXTENDED DIELECTRIC, N,G,T	N39	
2052-1352-00	RSA-3269	SMA, FEM 2-HOLE PANEL MNT, .590" EXTENDED DIELECTRIC, N,G,T	N39	N57
2052-1900-02	RSA-3269	SMA, FEM 2-HOLE PANEL MNT, .590" EXTENDED DIELECTRIC, N,G,T	N39	N57
2052-1901-02	RSA-3279	SMA, FEM 4-HOLE PANEL MNT, .590" EXTENDED DIELECTRIC, N,G,T	N39	N57
2054-0000-02	RSA-3285-03	SMA, FEM 4-HOLE R/A PANEL MNT, POST TERMINAL, N,G,T	N39	N57

2056-0000-02	RSA-3251	SMA, FEM BLKHD,SOLDER CUP, REAR MNT, N,G,T	N39	N57
2056-0000-02	RSA-3250	SMA, FEM BLKHD,SOLDER CUP, FRONT MNT, N,G,T	N10	
2056-1100-02	RSA-3251-1-10	SMA, FEM BLKHD,.430" (11.00MM) HEX FLGE W/GAS, G,G,T	N39	N57
2056-1900-02	RSA-3250	SMA, FEM BLKHD,SOLDER CUP, FRONT MNT, N,G,T	N39	N57
2056-5006-02	RSA-3250	SMA, FEM BLKHD,SOLDER CUP, FRONT MNT, N,G,T	N39	N57
2058-0000-02	RSA-3250	SMA, FEM BLKHD,SOLDER CUP, FRONT MNT, N,G,T	N39	N57
2058-0000-02	RSA-3251	SMA, FEM BLKHD,SOLDER CUP, REAR MNT, N,G,T	N10	
2062-0000-00	RSA-3350-1	SMA, FEM, VERTICAL PCB MNT, G,G,T		
2064-0000-00	RSA-3300-1	SMA, FEM, R/A PCB MNT, G,G,T		
2080-0000-02	RSA-3404	SMA FEM TO SMA FEM BARREL ADAPTER, N,G,T	N39	
2080-1900-02	RSA-3404	SMA FEM TO SMA FEM BARREL ADAPTER, N,G,T	N39	N57
2080-5055-02	RSA-3404	SMA FEM TO SMA FEM BARREL ADAPTER, N,G,T	N39	
2081-0000-02	RSA-3403-1	SMA MALE TO SMA MALE ADAPTER, G,G,T	N35	
2081-1900-2	RSA-3403	SMA MALE TO SMA MALE ADAPTER, N,G,T	N39	N57
2082-5133-02	RSA-3405	SMA MALE TO SMA FEM ADAPTER, N,G,T	N39	
2082-5133-02	RSA-3405-1	SMA MALE TO SMA FEM ADAPTER, G,G,T	N35	
2084-0000-02	RSA-3410	SMA FEM TO SMA FEM THRU-PANEL BLKHD, N,G,T	N39	
2084-0000-02	RSA-3410-1	SMA FEM TO SMA FEM THRU-PANEL BLKHD, G,G,T	N35	
2084-1900-02	RSA-3410	SMA FEM TO SMA FEM THRU-PANEL BLKHD, N,G,T	N39	
2084-1900-02	RSA-3410-1	SMA FEM TO SMA FEM THRU-PANEL BLKHD, G,G,T	N35	N57
2088-0000-02	RSA-3402	SMA MALE TO SMA FEM R/A ADAPTER, N,G,T	N39	
2088-1230-02	RSA-3402	SMA MALE TO SMA FEM R/A ADAPTER, N,G,T	N39	
2088-1230-02	RSA-3402-1	SMA MALE TO SMA FEM R/A ADAPTER, G,G,T	N35	
2088-5013-02	RSA-3402-1	SMA MALE TO SMA FEM R/A ADAPTER, G,G,T	N35	
2831-7316-02	RSA-3000-1B1	SMA, MALE 3 PIECE CRIMP, G,G,T; FOR RG-316 DBL SHIELD, CBL GRP B1	N35	N57
2831-7316-02	RSA-3000-B1	SMA, MALE 3 PIECE CRIMP, N,G,T; FOR RG-316 DBL SHIELD, CBL GRP B1	N39	N57
2831-7341-02	RSA-3000-C1	SMA, MALE CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
2831-7358-02	RSA-3000-1C	SMA, MALE 3 PIECE CRIMP, G,G,T; FOR RG-58/U, CBL GRP C	N35	N57
2831-7358-02	RSA-3000-B1	SMA, MALE 3 PIECE CRIMP, N,G,T; FOR RG-316 DBL SHIELD, CBL GRP B1	N39	N57
2831-7358-02	RSA-3000-C	SMA, MALE CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
2831-7388-02	RSA-3000-1B	SMA, MALE 3 PIECE CRIMP, G,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N35	N57
2831-7388-02	RSA-3000-B	SMA, MALE 3 PIECE CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N39	N57
2834-7316-02	RSA-3252-B1	SMA, FEM BLKHD CRIMP, N,G,T; FOR RG-316/U DBL SHIELD, CBL GRP B1	N39	N57
2834-7341-02	RSA-3050-C1	SMA, FEM CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1,		
2834-7341-02	RSA-3252-C1	SMA, FEM BLKHD CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N39	N57
2834-7358-02	RSA-3050-C	SMA, FEM CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
2834-7358-02	RSA-3252-C	SMA, FEM BLKHD CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N39	N57
2834-7388-02	RSA-3050-B	SMA, FEM STRAIGHT CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
2834-7388-02	RSA-3252-B	SMA, FEM BLKHD, W/O GASKET, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N39	N57
2837-7316-02	RSA-3010-B1	SMA, MALE R/A CRIMP, N,G,T; FOR RG-316 DBL SHIELD, CBL GRP B1	N39	N57
2837-7341-02	RSA-3000-C1	SMA, MALE CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N39	N57
2837-7341-02	RSA-3010-C1	SMA, MALE R/A CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N39	N57
2837-7358-02	RSA-3010-C	SMA, MALE R/A CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
2837-7358-02	RSA-3010-C	SMA, MALE R/A CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N39	N57
2837-7388-02	RSA-3010-1B	SMA, MALE R/A CRIMP, G,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N35	N57
2837-7388-02	RSA-3010-B	SMA, MALE R/A CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
2837-7388-02	RSA-3010-B	SMA, MALE R/A CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N39	N57
3001-7214-10	RFN-1006-3F	N, MALE CRIMP, S,G,T; FOR RG-9/U, CBL GRP F	N60	
3001-7341-10	RFN-1000-N	N, MALE SOLDER CLAMP, N,G,T; RG-58/U & RG-142/U, CBL GRP C, C1		
3001-7341-10	RFN-1022-8-C	N, FEM CRIMP, REAR MNT BLKHD, N,G,T; FOR RG-58/U, CBL GRP C	N60	
3001-7341-10	RFN-1022-8-C1	N, FEM CRIMP, REAR MNT BLKHD, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N60	
3001-7341-10	RFN-1000-1S	N, MALE SOLDER CLAMP, S,G,T; RG-58/U & RG-142/U, CBL GRP C, C1	N1	
3001-7841-00	RFN-1005-1SR2	N, MALE, N,G,T; FOR .141 SEMI-RIGID CABLE, CBL GRP SR2	N59	
3001-7885-00	RFN-1005-1SR1	N, MALE, N,G,T; FOR .085 SEMI-RIGID CABLE, CBL GRP SR1	N59	
3001-7941-00	RFN-1005-1SR2	N, MALE, N,G,T; FOR .141 SEMI-RIGID CABLE, CBL GRP SR2		
3001-7985-00	RFN-1005-1SR1	N, MALE, N,G,T; FOR .085 SEMI-RIGID CABLE, CBL GRP SR1		
3002-7341-10	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1	N1	
3004-7388-10	RFN-1022-8	N, FEM CRIMP, REAR MNT BLKHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N60	
3004-7841-00	RFN-1022-SR2	N, FEM BLKHD REAR MNT, N,G,T; FOR .141 SEMI-RIGID CBL, CBL GRP SR2	N59	

3004-7885-00	RFN-1022-SR1	N, FEM BLKHD REAR MNT, N,G,T; FOR.085 SEMI-RIGID CBL, CBL GRP SR1	N59	
3004-7941-00	RFN-1022-SR2	N, FEM BLKHD REAR MNT, N,G,T; FOR .141 SEMI-RIGID CBL, CBL GRP SR2		
3004-7985-00	RFN-1022-SR1	N, FEM BLKHD REAR MNT, N,G,T; FOR.085 SEMI-RIGID CBL, CBL GRP SR1		
3006-7341-10	RFN-1021-6	GRP C, C1	N1	
3031-7341-10	RFN-1005-3C1	N, MALE CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
3031-7358-10	RFN-1005-2N	N, MALE CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
3031-7358-10	RFN-1005-3C	N, MALE CRIMP, S,G,T; FOR RG-58/U, CBL GRP C	N1	
3031-7388-10	RFN-1005-B-03	N, MALE CRIMP, N,G,T; FOR RG-316, RG-174/U, CBL GRP B		
3032-7341-10	RFN-1027-C1	N, FEM CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N1	
3032-7358-10	RFN-1027	N, FEM CRIMP, S,G,T; FOR RG-58/U, CBL GRP C	N1	
3034-7358-10	RFN-1022-8-C	N, FEM CRIMP, REAR MNT BLKHD, N,G,T; FOR RG-58/U, CBL GRP C		
3034-7388-10	RFN-1022-8	N, FEM CRIMP, REAR MNT BLKHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
3034-7388-10	RFN-1022-8-C1	N, FEM CRIMP, REAR MNT BLKHD, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
3051-0000-10	RFN-1041-1	N, MALE 4-HOLE PANEL MNT, SOLDER CUP, S,G,T	N1	
3052-0000-10	RFN-1021-2	N, FEM 4-HOLE PANEL MNT. UG-58A/U, N,G,T		
3052-0000-10	RFN-1021	N, FEM, 4-HOLE PANEL MNT, S,G,T	N1	
3080-0000-00	RFN-1013-1	N FEM TO N FEM BARREL ADAPTER, S,G,T	N1	
3080-2240-00	RSA-3477	SMA FEM TO N FEM ADAPTER, N,G,T	N39	
3080-2242-00	RSA-3290	SMA FEM TO N FEM ADAPTER, 4-HOLE PANEL MNT, ST STEEL SS-G-T	N12	
3080-2320-00	RFN-1039-1	N FEM TO BNC FEM ADAPTER, S,G,T	N1	
3081-2241-00	RSA-3478	SMA FEM TO N MALE ADAPTER, N,G,T	N10	
3081-2241-00	RSA-3453	SMA MALE TO N MALE ADAPTER, N,G,T	N12	
3081-2321-00	RFN-1040-1	N MALE TO BNC MALE ADAPTER, S,G,T	N1	
3082-2240-00	RSA-3478	SMA FEM TO N MALE ADAPTER, N,G,T	N12	
3082-2241-00	RSA-3452	SMA MALE TO N FEM ADAPTER, N,G,T	N12	
3082-2242-00	RSA-3477	SMA FEM TO N FEM ADAPTER, N,G,T	N10	
3082-2320-00	RFN-1037-1	N MALE TO BNC FEM ADAPTER, S,G,T	N1	
3082-2321-00	RFN-1038-1	N FEM TO BNC MALE ADAPTER, S,G,T	N1	
3084-2240-00	RSA-3477-03	ADAPTER, N,G,T	N39	
3101-7341-10	RFT-1200	TNC, MALE SOLDER CLAMP, N,G,T; FOR RG-142/U & RG58/U, CBL GRP C,C1		
3101-7341-10	RFT-1200-C1*	TNC MALE SOLDER CLAMP FOR FUGIKURA, 5D-FB, N,G,T		
3101-7388-10	RFT-1200-1B*	TNC, MALE SOLDER CLAMP, FOR RG-174/U, CBL GRP B, N,G,T		
3104-7885-00	RFT-1212-SR1*	TNC, FEM BLKHD CRIMP, HEX FLANGE, GASKET FOR .085 SEMI RIGID, N,G,T	N59	
3104-7985-00	RFT-1212-SR1*	TNC, FEM BLKHD CRIMP, HEX FLANGE, GASKET FOR .085 SEMI RIGID, N,G,T	N32	
3131-7341-10	RFT-1202-C1	TNC, MALE CRIMP, N,G,D; RG-142/U & RG-55/U, CBL GRP C1		
3131-7358-10	RFT-1202-2	TNC, MALE CRIMP, N,G,D; FOR RG-58/U, CBL GRP C		
3131-7358-10	RFT-1202-2T	TNC, MALE CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
3131-7388-10	RFT-1202-3	TNC, MALE CRIMP, N,G,D; RG-174/U & RG-316/U, CBL GRP B		
3132-7341-10	RFT-1216-C1	TNC, FEM CRIMP, N,G,D; FOR RG-142/U & RG-55/U, CBL GRP C1		
3132-7358-10	RFT-1216-1	TNC, FEM CRIMP, N,G,D; FOR RG-58/U, CBL GRP C		
3134-7341-10	RFT-1212-C1	TNC, FEM BLKHD CRIMP, N,G,D; FOR RG-142/U & RG-55/U, CBL GRP C1		
3134-7358-10	RFT-1212	TNC, FEM CRIMP BLKHD, N,G,D; FOR RG-58/U, CBL GRP C		
3152-0000-10	RFT-1210	TNC, FEM 4-HOLE PANEL MNT, N,G,T		
3152-1628-10	RFT-1210	TNC, FEM 4-HOLE PANEL MNT, N,G,T		
3180-0000-00	RFT-1225	TNC FEM TO FEM BARREL ADAPTER, N,G,T		
3180-2240-00	RSA-3473	SMA FEM TO TNC FEM ADAPTER, N,G,T	N39	
3180-2242-00	RFT-1241-4	TNC FEM TO SMA FEM(MOTORLA) ADAPTER, N,G,T	N39	
3180-2320-00	RFT-1232	TNC FEM TO BNC FEM ADAPTER, N,G,T		
3181-2241-00	RSA-3454	SMA MALE TO TNC MALE ADAPTER, N,G,T	N39	
3182-2240-00	RSA-3472	SMA FEM TO TNC MALE ADAPTER, N,G,T	N39	
3182-2241-00	RFT-1241-6	TNC FEM TO SMA MALE, N,G,T	N39	
3182-2320-00	RFT-1231	TNC MALE TO BNC FEM ADAPTER, N,G,T		
3182-2321-00	RFT-1230	TNC FEM TO BNC MALE ADAPTER, N,G,T		
3201-7341-10	RFB-1100-2	C,C1		
3201-7341-10	RFB-1100-2ST	C,C1	N1	
3201-7388-10	RFB-1100-B	BNC MALE SOLDER CLAMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
3202-7341-10	RFB-1123-1	BNC FEM CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
3202-7341-10	RFB-1123-C1	BNC FEMALE CRIMP, N,G,T; RG-142/U & RG-55/U, CBL GRP C1		
3204-7341-10	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C		

3204-7341-10	RFB-1117-BT-03	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .14"		
3204-7388-10	RFB-1117-BT	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .20"		
3204-7388-10	RFB-1117-BT-03	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .14"		
3231-7341-10	RFB-1106-2TC1	BNC MALE CRIMP PLUG, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
3231-7341-10	RFB-1106-C1	BNC MALE CRIMP, CBL GRP C1, S-G-T		
3231-7358-10	RFB-1106-2	BNC MALE CRIMP PLUG, N,G,D; FOR RG58/U, CBL GRP C		
3231-7358-10	RFB-1106-2T	BNC MALE CRIMP PLUG, N,G,T; FOR RG58/U, CBL GRP C		
3231-7358-10	RFB-1106-2ST	BNC MALE CRIMP PLUG, S,G,T; FOR RG58/U, CBL GRP C	N1	
3231-7388-10	RFB-1106-5	BNC MALE CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, (LG. FERR), CBL GRP B		
3232-7341-10	RFB-1123-C1	BNC FEMALE CRIMP, N,G,T; RG-142/U & RG-55/U, CBL GRP C1		
3232-7358-10	RFB-1123-1	BNC FEM CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
3234-7341-10	RFB-1117-C1	BNC, FEM CRIMP BULKHD, N,G,D; FOR RG-142/U & RG-55/U, CBL GRP C1, REAR MOUNT, D-FLAT		
3234-7358-10	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C		
3234-7388-10	RFB-1117-BT	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .20"		
3234-7388-10	RFB-1117-BT	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .20"		
323-7341-10	RFB-1123-C1	BNC FEMALE CRIMP, N,G,T; RG-142/U & RG-55/U, CBL GRP C1		
3252-0000-10	RFB-1115	BNC FEM CHASSIS 4-HOLE MNT, N,G,T		
3252-0000-10	RFB-1115-S	BNC FEM, 4 HOLE PANEL MNT, SOLDER CUP, S,G,T	N1	
3280-0000-10	RFB-1134	BNC FEM TO BNC FEM BARREL ADAPTER, N,S,D		
3280-2240-00	RFB-1142	BNC FEM TO SMA FEM ADAPTER, N,G,T	N39	
3281-0000-10	RFB-1133	BNC MALE TO BNC MALE ADAPTER, N,S,T		
3281-2241-00	RSA-3459	SMA MALE TO BNC MALE ADAPTER, N,G,T		
3282-2240-00	RSA-3476	SMA FEM TO BNC MALE ADAPTER, N,G,T	N39	
3282-2240-00	RSA-3476-1	SMA FEM TO BNC MALE ADAPTER, G,G,T		
3282-2241-00	RSA-3458	SMA MALE TO BNC FEM ADAPTER, N,G,T	N12	
35001-10	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
35007E	RFB-1115-S	BNC FEM, 4 HOLE PANEL MNT, SOLDER CUP, S,G,T		
35007H	RFB-1115	BNC FEM CHASSIS 4-HOLE MNT, N,G,T		
35010-10	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
35070 A10	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
35070 A10	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
35070 C10	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
35070 C22	RFB-1100-B	BNC MALE SOLDER CLAMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
35070-10	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
35070-10	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
35098/75R	RFB-1750	BNC 75 OHM MALE TERMINATION, 75 OHM 1/2 WATT N-G-T		
35103C1	RFB-1101-1EN	BNC MALE SOLDER CLAMP, N,G,D; FOR RG-8/U & RG-213/U, CBL GRP E		
35141D10	RFB-1106-2	BNC MALE CRIMP PLUG, N,G,D; FOR RG58/U, CBL GRP C		
35141D60	RFB-1106-2TC1	BNC MALE CRIMP PLUG, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
35141D60	RFB-1106-C1	BNC MALE CRIMP, CBL GRP C1, S-G-T		
35143D10	RFB-1123-1	BNC FEM CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
35143D60	RFB-1123-C1	BNC FEMALE CRIMP, N,G,T; RG-142/U & RG-55/U, CBL GRP C1		
35145D10	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C		
35145D22	RFB-1117-BT	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .20"		
35145D60	RFB-1117-C1	BNC, FEM CRIMP BULKHD, N,G,D; FOR RG-142/U & RG-55/U, CBL GRP C1, REAR MOUNT, D-FLAT		
3514D22	RFB-1106-5	BNC MALE CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, (LG. FERR), CBL GRP B		

35228D10	RFB-1110-1	BNC MALE R/A CRIMP PLUG, N,G,T; RG-58/U, CBL GRP C		
35228D60	RFB-1110-C1	BNC MALE R/A CRIMP PLUG, N,G,T; FOR RG-55/U & RG-142/U, CBL GRP C1		
35282W	RFB-1113-W-04	BNC FEM, R/A HI-PROFILE PCB MNT,(WHITE), A-G-P; POST LEG; W/ NO HARDWARE		
35283W	RFB-1112-1W-04	BNC FEM VERT LOW-PROFILE PCB MNT, (WHITE), A,G,P; POST LEG; W/ NO HARDWARE		
3680-0000-02	RFN-1013-1	N FEM TO N FEM BARREL ADAPTER, S,G,T		
3680-2240-00	RSA-3477	SMA FEM TO N FEM ADAPTER, N,G,T	N39	
3680-2310-02	RFT-1239	TNC FEM TO N FEM ADAPTER, N,G,T	N39	
3681-0000-02	RFN-1014-1	N MALE TO N MALE ADAPTER, S,G,T		
3682-2310-02	RFT-1233	TNC FEM TO N MALE ADAPTER, N,G,T	N39	
3682-2311-02	RFT-1234	TNC MALE TO N FEM ADAPTER, N,G,T	N39	
3684-2240-00	RSA-3477-03	SMA FEM TO N FEM FEED THROUGH W/GASKET & DBL D FLAT BULKHEAD ADAPTER, N,G,T	N39	
37141D25	RFB-1707-2	BNC 75 OHM MALE CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
37141D7	RFB-1708-1T	BNC 75 OHM MALE CRIMP, S,G,T; FOR BELDEN 8281, CBL GRP G		
37143D25	RFB-1724	BNC 75 OHM FEM CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
37145D25	RFB-1717	BNC 75 OHM FEM CRIMP BULKHEAD, REAR MNT, N,G,D; FOR RG-59/U, CBL GRP D		
37241D2511	RFB-1707-2	BNC 75 OHM MALE CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
37243D25/1	RFB-1724	BNC 75 OHM FEM CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
37245D25/1	RFB-1717	BNC 75 OHM FEM CRIMP BULKHEAD, REAR MNT, N,G,D; FOR RG-59/U, CBL GRP D		
37571C7	RFB-1701-G	BNC 75 OHM MALE SOLDER CLAMP, N,S,T; FOR BELDEN 8281, CBL GRP G		
5101-5007-09	RSB-4100-B	SMB CLAMP PLUG, N,G,T; RG-174/U & RG-316/U, CBL GRP B		
5101-5007-10	RSB-4100-B	SMB CLAMP PLUG, N,G,T; RG-174/U & RG-316/U, CBL GRP B		
5131-5007-09	RSB-4000-B-03	SMB CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N12	
5131-5007-09	RSB-4000-B	SMB CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N12	
5131-5007-10	RSB-4000-B	SMB CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
5131-5007-10	RSB-4000-B-03	SMB CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
5132-5001-09	RSB-4050-1B	SMB JACK CRIMP, G, G, T; RG-174/U & RG-316/U, CBL GRP B		
5132-5001-09	RSB-4050-B	SMB JACK CRIMP, N, G, T; RG-174/U & RG-316/U, CBL GRP B		
5132-5001-10	RSB-4050-1B	SMB JACK CRIMP, G, G, T; RG-174/U & RG-316/U, CBL GRP B	N60	
5132-5001-10	RSB-4050-B	SMB JACK CRIMP, N, G, T; RG-174/U & RG-316/U, CBL GRP B		
5134-5002-09	RSB-4252-B	SMB JACK, CRIMP BLKHD, REAR MNT, W/ D-FLAT, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N12	
5134-5002-10	RSB-4252-B	SMB JACK, CRIMP BLKHD, REAR MNT, W/ D-FLAT, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
5137-5010-09	RSB-4010-1B	SMB PLUG, R/A CRIMP, G,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
5137-5010-09	RSB-4010-B	SMB PLUG, R/A CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N12	
5137-5010-10	RSB-4010-B	SMB PLUG, R/A CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
5152-0000-09	RSB-4271	SMB JACK, 4-HOLE FLANGE PANEL MNT, N,G,T	N12	
5158-0000-09	RSB-4251	SMB JACK, BLKHD, REAR MNT, N,G,T	N12	
5158-0000-09	RSB-4251-1	SMB JACK, BLKHD, REAR MNT, G,G,T		
5158-5010-09	RSB-4251	SMB JACK, BLKHD, REAR MNT, N,G,T	N12	
5158-5010-09	RSB-4251-1	SMB JACK, BLKHD, REAR MNT, G,G,T		
5162-5013-09	RSB-4450-1	SMB PLUG, VERTICAL PCB MNT, G,G,T		
5162-5013-09	RSB-4350	SMB JACK, VERT PCB MNT, N,G,T	N12	
5162-5013-10	RSB-4350	SMB JACK, VERT PCB MNT, N,G,T		
5164-5003-09	RSB-4300	SMB JACK, R/A PCB MNT, N,G,T		
5164-5003-09	RSB-4300-1	SMB JACK, R/A PCB MNT, G,G,T		
5164-5003-09	RSB-4300	SMB JACK, R/A PCB MNT, N,G,T	N12	
5164-5011-09	RSB-4301-1	SMB JACK, R/A BLKHD PCB MNT, G,G,T		
5180-2240-00	RSA-3406	SMA FEMALE TO SMB JACK ADAPTER, N,G,T	N39	
5180-2240-00	RSA-3406-1	SMA FEMALE TO SMB JACK ADAPTER, G,G,T	N35	
5807-5000-09	RMX-8010-B	MCX, MALE R/A CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N12	
5831-5001-00	RMX-8000-B	MCX, MALE STRAIGHT CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
5831-5002-10	RMX-8000-A*	MCX, MALE STRAIGHT CRIMP PLUG, N,G,T; FOR RG-178/U, CBL GRP A, N,G,T		
5831-5003-10	RMX-8000-B	MCX, MALE STRAIGHT CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
5837-5002-10	RMX-8010-A	MCX, MALE R/A CRIMP PLUG, N,G,T; FOR RG-178/U, CBL GRP A, N,G,T		
5837-5003-10	RMX-8010-B	MCX, MALE R/A CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
5837-5010-63	RMX-8010-B1	MCX, MALE R/A CRIMP PLUG, N,G,T; FOR RG-316 DBL SHIELD, CBL GRP B1	N12	
5862-5003-10	RMX-8350	MCX, FEM VERTICAL PCB MNT, N,G,T		

5863-0000-10	RMX-8450-1	MCX, MALE VERTICAL PCB MNT, G,G,T		
5864-5001-10	RMX-8300	MCX, FEM R/A PCB MNT, N,G,T		
A55 P04 E999 X99	RFN-1038-1	N FEM TO BNC MALE ADAPTER, S,G,T	N9	
A55 P04 H999 X99	RFN-1038-1	N FEM TO BNC MALE ADAPTER, S,G,T	N1	N9
A55 P04 J999 X99	RFN-1038-1	N FEM TO BNC MALE ADAPTER, S,G,T	N1	
A55 P07 H999 X99	RFB-1137	BNC FEM TO UHF MALE ADAPTER, N,S,D	N9	
A55 P07 J999 X99	RFB-1137	BNC FEM TO UHF MALE ADAPTER, N,S,D		
A55 P08 H999 X99	RFB-1136	BNC MALE TO UHF FEM ADAPTER, N,S,D	N9	
A55 P08 J999 X99	RFB-1136	BNC MALE TO UHF FEM ADAPTER, N,S,D		
A55 P09 E999 X99	RFN-1036-1	N FEM TO UHF MALE ADAPTER, S,G,T	N9	
A55 P09 E999 XCP	RFN-1036-1	N FEM TO UHF MALE ADAPTER, S,G,T		
A55 P09 H999 X99	RFN-1036-1	N FEM TO UHF MALE ADAPTER, S,G,T	N1	N9
A55 P09 H999 XCP	RFN-1036-1	N FEM TO UHF MALE ADAPTER, S,G,T		
A55 P09 J999 X99	RFN-1036-1	N FEM TO UHF MALE ADAPTER, S,G,T	N1	
A55 P09 J999 XCP	RFN-1036-1	N FEM TO UHF MALE ADAPTER, S,G,T		
A55 P21 E999 X99	RFD-1671-2	7/16 DIN MALE TO N FEM ADAPTER, S,S,T		
A55 P22 E999 X99	RFD-1673-2	7/16 DIN FEM TO N FEM ADAPTER, S,G,T		
A55 P23 E999 X99	RFD-1670-2	7/16 DIN MALE TO N MALE ADAPTER, S,S,T		
A55 P24 E999 X99	RFD-1672-2	7/16 DIN FEM TO N MALE ADAPTER, S,S,T		
A55 P28 E999 X99	RFN-1037-1	N MALE TO BNC FEM ADAPTER, S,G,T	N9	
A55 P28 E999 XCP	RFN-1037-1	N MALE TO BNC FEM ADAPTER, S,G,T		
A55 P28 H999 X99	RFN-1037-1	N MALE TO BNC FEM ADAPTER, S,G,T	N1	N9
A55 P28 H999 XCP	RFN-1037-1	N MALE TO BNC FEM ADAPTER, S,G,T		
A55 P28 J999 X99	RFN-1037-1	N MALE TO BNC FEM ADAPTER, S,G,T	N1	
A55 P28 J999 XCP	RFN-1037-1	N MALE TO BNC FEM ADAPTER, S,G,T		
A55 P31 H999 X99	RFU-545	UHF FEM TO BNC FEM ADAPTER, N,S,D	N9	
A55 P31 J999 X99	RFU-545	UHF FEM TO BNC FEM ADAPTER, N,S,D		
A55 P32 E999 X99	RFN-1035-1	N MALE TO UHF FEM ADAPTER, S,G,T	N9	
A55 P32 E999XCP	RFN-1035-1	N MALE TO UHF FEM ADAPTER, S,G,T		
A55 P32 H999 X99	RFN-1035-1	N MALE TO UHF FEM ADAPTER, S,G,T	N1	N9
A55 P32 H999 XCP	RFN-1035-1	N MALE TO UHF FEM ADAPTER, S,G,T		
A55 P32 J999 X99	RFN-1035-1	N MALE TO UHF FEM ADAPTER, S,G,T	N1	
A55 P32 J999 XCP	RFN-1035-1	N MALE TO UHF FEM ADAPTER, S,G,T		
A55 P38 H999 X99	RFT-1231	TNC MALE TO BNC FEM ADAPTER, N,G,T	N9	
A55 P38 J999 X99	RFT-1231	TNC MALE TO BNC FEM ADAPTER, N,G,T		
B35 A03 E001 X99	RFB-1101-1EN	BNC MALE SOLDER CLAMP, N,G,D; FOR RG-8/U & RG-213/U, CBL GRP E		
B35 A98 H010 X99	RFB-1104	BNC MALE TWIST-ON PLUG, N,S,D; FOR RG58/U, CBL GRP C		
B35 A01 J010 X99	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
B35 A03 H001 X99	RFB-1101-1EN	BNC MALE SOLDER CLAMP, N,G,D; FOR RG-8/U & RG-213/U, CBL GRP E	N9	
B35 A03 J001 X99	RFB-1101-1EN	BNC MALE SOLDER CLAMP, N,G,D; FOR RG-8/U & RG-213/U, CBL GRP E		
B35 A06 H010 X99	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N1	N9
B35 A06 H010 X99	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N9	
B35 A06 J010 X99	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
B35 A06 J010 X99	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N1	
B35 A07 H010 X99	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N1	N9
B35 A07 H010 X99	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N9	
B35 A07 J010 X99	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
B35 A07 J010 X99	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N1	
B35 A11 J010 X99	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
B35 A11 J010 XCP	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1		

B35 A18 H010 X99	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N1	N9
B35 A18 H010 X99	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N9	
B35 A18 J010 X99	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
B35 A18 J010 X99	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N1	
B35 A41 E010 X99	RFB-1106-2ST	BNC MALE CRIMP PLUG, S,G,T; FOR RG58/U, CBL GRP C	N9	
B35 A41 H010 X99	RFB-1106-2	BNC MALE CRIMP PLUG, N,G,D; FOR RG58/U, CBL GRP C	N9	
B35 A41 H010 X99	RFB-1106-2T	BNC MALE CRIMP PLUG, N,G,T; FOR RG58/U, CBL GRP C	N9	
B35 A41 H060 X99	RFB-1106-C1	BNC MALE CRIMP, CBL GRP C1, S-G-T	N9	
B35 A41 J010 X99	RFB-1106-2	BNC MALE CRIMP PLUG, N,G,D; FOR RG58/U, CBL GRP C		
B35 A41 J010 X99	RFB-1106-2T	BNC MALE CRIMP PLUG, N,G,T; FOR RG58/U, CBL GRP C		
B35 A41 J010 XCP	RFB-1106-2	BNC MALE CRIMP PLUG, N,G,D; FOR RG58/U, CBL GRP C		
B35 A41 J022 XCP	RFB-1106-5	BNC MALE CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, (LG. FERR), CBL GRP B		
B35 A41 J060 X99	RFB-1106-2TC1	BNC MALE CRIMP PLUG, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
B35 A41 J060 X99	RFB-1106-C1	BNC MALE CRIMP, CBL GRP C1, S-G-T		
B35 A41 JB10 XCP	RFB-1106-2T	BNC MALE CRIMP PLUG, N,G,T; FOR RG58/U, CBL GRP C		
B35 A70 H010 X99	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N1	N9
B35 A70 H010 X99	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N9	
B35 A70 H022 X99	RFB-1100-B	BNC MALE SOLDER CLAMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N9	
B35 A70 J010 X99	RFB-1100-2	BNC MALE SOLDER CLAMP, N,G,D; FOR RG58/U & RG-142/U & RG-55/U, CBL GRP C,C1		
B35 A70 J010 X99	RFB-1100-2ST	BNC MALE SOLDER CLAMP, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C,C1	N1	
B35 A70 J022 X99	RFB-1100-B	BNC MALE SOLDER CLAMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
B35 B02 E010 X99	RFB-1110-C-04	BNC MALE R/A CLAMP PLUG, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C, C1		
B35 B02 J010 X99	RFB-1110-C-04	BNC MALE R/A CLAMP PLUG, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C, C1		
B35 B12 E010 X99	RFB-1110-C-04	BNC MALE R/A CLAMP PLUG, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C, C1		
B35 B12 J010 X99	RFB-1110-C-04	BNC MALE R/A CLAMP PLUG, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C, C1		
B35 B28 B060 X99	RFB-1110-C1	BNC MALE R/A CRIMP PLUG, N,G,T; FOR RG-55/U & RG-142/U, CBL GRP C1		
B35 B28 E010 X99	RFB-1110-1	BNC MALE R/A CRIMP PLUG, N,G,T; RG-58/U, CBL GRP C		
B35 B28 H010 X99	RFB-1110-1	BNC MALE R/A CRIMP PLUG, N,G,T; RG-58/U, CBL GRP C	N9	
B35 B28 H060 X99	RFB-1110-C1	BNC MALE R/A CRIMP PLUG, N,G,T; FOR RG-55/U & RG-142/U, CBL GRP C1	N9	
B35 B28 J010 X99	RFB-1110-1	BNC MALE R/A CRIMP PLUG, N,G,T; RG-58/U, CBL GRP C		
B35 B28 J010 X99	RFB-1110-C-04	BNC MALE R/A CLAMP PLUG, S,G,T; FOR RG-58/U & RG-142/U & RG-55/U, CBL GRP C, C1	N1	
B35 B28 J010 XCP	RFB-1110-1	BNC MALE R/A CRIMP PLUG, N,G,T; RG-58/U, CBL GRP C		
B35 B28 J060 X99	RFB-1110-C1	BNC MALE R/A CRIMP PLUG, N,G,T; FOR RG-55/U & RG-142/U, CBL GRP C1		
B35 D76 H999 X99	RFB-1143	BNC MALE BLKHD PLUG, FRONT MNT, D-FLAT, N,G,T	N9	
B35 D76 J999 X99	RFB-1143	BNC MALE BLKHD PLUG, FRONT MNT, D-FLAT, N,G,T		
B35 E43 E010 X99	RFB-1123-1	BNC FEM CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
B35 E43 E060 X99	RFB-1123-C1	BNC FEMALE CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
B35 E43 H010 X99	RFB-1123-1	BNC FEM CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N9	
B35 E43 H060 X99	RFB-1123-C1	BNC FEMALE CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N9	
B35 E43 J010 X99	RFB-1123-1	BNC FEM CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
B35 E43 J010 XCP	RFB-1123-1	BNC FEM CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
B35 E43 J060 X99	RFB-1123-C1	BNC FEMALE CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
B35 H03 H025 X99	RFB-1717-D	BNC 75 OHM FEM BULKHEAD CRIMP, REAR MOUNT, D-FLAT, O-RING, N,G,T; FOR RG-59/U, CBL GRP D	N57	
B35 H05 H010 X99	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C		
B35 H06 H010 X99	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C		
B35 H07 H010 X99	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C	N57	
B35 H30 H022 X99	RFB-1117-BT	BNC FEM CRIMP BLKHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .20"	N57	

B35 H30 H024 X99	RFB-1117-A	BNC FEM CRIMP BLKHD JACK, REAR MOUNT W/D-FLAT & O-RING, RG-178/U, N,G,T	N57	
B35 H39 H010 X99	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C	N57	
B35 H39 H022 X99	RFB-1117-BT	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .20"		
B35 H45 E010 X99	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C		
B35 H45 E060 X99	RFB-1117-C1	BNC, FEM CRIMP BULKHD, N,G,D; FOR RG-142/U & RG-55/U, CBL GRP C1, REAR MOUNT, D-FLAT		
B35 H45 H010 X99	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C	N9	
B35 H45 H022 X99	RFB-1117-BT	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .20"	N9	
B35 H45 H060 X99	RFB-1117-C1	BNC, FEM CRIMP BULKHD, N,G,D; FOR RG-142/U & RG-55/U, CBL GRP C1, REAR MOUNT, D-FLAT	N9	
B35 H45 J010 X99	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C		
B35 H45 J010 XCP	RFB-1117	BNC FEM CRIMP BLKHD, N,G,D; FOR RG58U, CBL GRP C		
B35 H45 J022 X99	RFB-1117-BT	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .20"		
B35 H45 J022 X99	RFB-1117-BT	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .20"		
B35 H45 J060 X99	RFB-1117-C1	BNC, FEM CRIMP BULKHD, N,G,D; FOR RG-142/U & RG-55/U, CBL GRP C1, REAR MOUNT, D-FLAT		
B35 K07 E999 H99	RFB-1115-S	BNC FEM, 4 HOLE PANEL MNT, SOLDER CUP, S,G,T	N9	
B35 K07 H999 H99	RFB-1115	BNC FEM CHASSIS 4-HOLE MNT, N,G,T	N9	
B35 K07 J999 H99	RFB-1115	BNC FEM CHASSIS 4-HOLE MNT, N,G,T		
B35 K07 J999 HCP	RFB-1115	BNC FEM CHASSIS 4-HOLE MNT, N,G,T		
B35 M27 E999 X99	RFB-1116-SG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, S,G,T		
B35 M27 J999 X99	RFB-1116-NG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, N,G,T		
B35 M27 J999 XCP	RFB-1116-NG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, N,G,T		
B35 M29 E999 X99	RFB-1116-SG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, S,G,T		
B35 M29 H999 X99	RFB-1116-NG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, N,G,T		
B35 M29 J999 X99	RFB-1116-NG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, N,G,T		
B35 M43 999 X99	RFB-1116-I	BNC FEM,INSULATED,BLKHD FRONT MOUNT, SOLDER CUP, N,G,A		
B35 M46 J999 X99	RFB-1116-I	BNC FEM,INSULATED,BLKHD FRONT MOUNT, SOLDER CUP, N,G,A		
B35 M66 E999 X99	RFB-1116-SG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, S,G,T	N9	
B35 M66 H999 X99	RFB-1116	BNC FEM DIECAST BLKHD, SOLDER CUP, N,G,D	N9	
B35 M66 H999 X99	RFB-1116-NG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, N,G,T	N9	
B35 M66 J999 X99	RFB-1116	BNC FEM DIECAST BLKHD, SOLDER CUP, N,G,D		
B35 M66 J999 X99	RFB-1116-NG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, N,G,T		
B35 M84 H999 X99	RFB-1116-NG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, N,G,T		
B35 M84 J999 X99	RFB-1116-NG	BNC FEM 1- HOLE BLKHD, SOLDER CUP, N,G,T		
B35 N61 E999 X99	RFB-1115-4	BNC FEM VERT PCB MNT, 4 LEGS , S,G,T		
B35 N62 E999 X99	RFB-1115-4	BNC FEM VERT PCB MNT, 4 LEGS , S,G,T	N9	
B35 N63 E999 X99	RFB-1115-4	BNC FEM VERT PCB MNT, 4 LEGS , S,G,T		
B35 N82 999 099	RFB-1113-B-04	BNC FEM R/A HI-PROFILE PCB MNT, (BLACK), A-G-P; POST LEG;W/ NO HARDWARE		
B35 N82 999 099	RFB-1113-W-04	BNC FEM, R/A HI-PROFILE PCB MNT,(WHITE), A-G-P; POST LEG; W/ NO HARDWARE		
B35 N82 H999 099	RFB-1113-B	BNC FEM R/A HI-PROFILE PCB MNT, (BLACK), A-G-P; POST LEG; W/ HARDWARE	N9	
B35 N82 H999 999	RFB-1113-W	BNC FEM, R/A HI-PROFILE PCB MNT,(WHITE), A-G-P; POST LEG; W/ HARDWARE	N9	
B35 N82 J999 099	RFB-1113-B	BNC FEM R/A HI-PROFILE PCB MNT, (BLACK), A-G-P; POST LEG; W/ HARDWARE		
B35 N82 J999 999	RFB-1113-W	BNC FEM, R/A HI-PROFILE PCB MNT,(WHITE), A-G-P; POST LEG; W/ HARDWARE		
B35 N83 999 099	RFB-1112-1B-04	BNC FEM VERT LOW-PROFILE PCB MNT,(BLACK), A,G,P; POST LEG; W/ NO HARDWARE		
B35 N83 999 099	RFB-1112-1W-04	BNC FEM VERT LOW-PROFILE PCB MNT, (WHITE), A-G-P; POST LEG; W/ NO HARDWARE		
B35 N83 H999 099	RFB-1112-1B	BNC FEM VERT LOW-PROFILE PCB MNT,(BLACK), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N83 H999 099	RFB-1113-1B	BNC FEM VERT HI-PROFILE PCB MNT,(BLACK), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N83 H999 099	RFB-1113-1W	BNC FEM VERT HI-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N83 H999 999	RFB-1112-1W	BNC FEM VERT LOW-PROFILE PCB MNT, (WHITE), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N83 H999 999	RFB-1113-1B	BNC FEM VERT HI-PROFILE PCB MNT,(BLACK), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N83 H999 999	RFB-1113-1W	BNC FEM VERT HI-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ HARDWARE	N9	

B35 N83 J999 099	RFB-1112-1B	BNC FEM VERT LOW-PROFILE PCB MNT,(BLACK), A,G,P; POST LEG; W/ HARDWARE		
B35 N83 J999 099	RFB-1113-1B	BNC FEM VERT HI-PROFILE PCB MNT,(BLACK), A,G,P; POST LEG; W/ HARDWARE		
B35 N83 J999 099	RFB-1113-1W	BNC FEM VERT HI-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ HARDWARE		
B35 N83 J999 999	RFB-1112-1W	BNC FEM VERT LOW-PROFILE PCB MNT, (WHITE), A,G,P; POST LEG; W/ HARDWARE		
B35 N88 999 099	RFB-1112-B-04	BNC FEM R/A LOW-PROFILE PCB MNT 50 OHM, (BLACK), A,G,P; POST LEG; W/ NO HARDWARE		
B35 N88 999 999	RFB-1112-W-04	BNC FEM R/A LOW-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ NO HARDWARE		
B35 N88 H999 099	RFB-1112-B	BNC FEM R/A LOW-PROFILE PCB MNT 50 OHM, (BLACK), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N88 H999 099	RFB-1112-B	BNC FEM R/A LOW-PROFILE PCB MNT 50 OHM, (BLACK), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N88 H999 099	RFB-1112-W	BNC FEM R/A LOW-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N88 H999 999	RFB-1112-B	BNC FEM R/A LOW-PROFILE PCB MNT 50 OHM, (BLACK), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N88 H999 999	RFB-1112-W	BNC FEM R/A LOW-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N88 H999 999	RFB-1112-W	BNC FEM R/A LOW-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ HARDWARE	N9	
B35 N88 J999 099	RFB-1112-B	BNC FEM R/A LOW-PROFILE PCB MNT 50 OHM, (BLACK), A,G,P; POST LEG; W/ HARDWARE		
B35 N88 J999 099	RFB-1112-B	BNC FEM R/A LOW-PROFILE PCB MNT 50 OHM, (BLACK), A,G,P; POST LEG; W/ HARDWARE		
B35 N88 J999 099	RFB-1112-W	BNC FEM R/A LOW-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ HARDWARE		
B35 N88 J999 999	RFB-1112-B	BNC FEM R/A LOW-PROFILE PCB MNT 50 OHM, (BLACK), A,G,P; POST LEG; W/ HARDWARE		
B35 N88 J999 999	RFB-1112-W	BNC FEM R/A LOW-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ HARDWARE		
B35 N88 J999 999	RFB-1112-W	BNC FEM R/A LOW-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ HARDWARE		
B35 N88 J999 OCP	RFB-1112-B	BNC FEM R/A LOW-PROFILE PCB MNT 50 OHM, (BLACK), A,G,P; POST LEG; W/ HARDWARE		
B35 N88 J999 OCP	RFB-1112-W	BNC FEM R/A LOW-PROFILE PCB MNT,(WHITE), A,G,P; POST LEG; W/ HARDWARE		
B35 P17 H999 X99	RFB-1130-5	BNC MALE TO DOUBLE BNC FEM GOALPOST ADAPTER, N-G-D	N9	
B35 P17 J999 X99	RFB-1130-5	BNC MALE TO DOUBLE BNC FEM GOALPOST ADAPTER, N-G-D		
B35 P17 J999 XCP	RFB-1130-5	BNC MALE TO DOUBLE BNC FEM GOALPOST ADAPTER, N-G-D		
B35 P28 H999 X99	RFB-1132	BNC MALE TO BNC FEM R/A ADAPTER, N,S,T	N9	
B35 P28 J999 X99	RFB-1132	BNC MALE TO BNC FEM R/A ADAPTER, N,S,T		
B35 P28 J999 XCP	RFB-1132	BNC MALE TO BNC FEM R/A ADAPTER, N,S,T		
B35 P31 E999 X99	RFB-1130	BNC T ADAPTER 2 FEM-1 MALE, N,G,T		
B35 P31 H999 X99	RFB-1130	BNC T ADAPTER 2 FEM-1 MALE, N,G,T	N9	
B35 P31 J999 X99	RFB-1130	BNC T ADAPTER 2 FEM-1 MALE, N,G,T		
B35 P31 J999 XCP	RFB-1130	BNC T ADAPTER 2 FEM-1 MALE, N,G,T		
B35 P32 H999 X99	RFB-1133	BNC MALE TO BNC MALE ADAPTER, N,S,T	N9	
B35 P32 J999 X99	RFB-1133	BNC MALE TO BNC MALE ADAPTER, N,S,T		
B35 P34 H999 X99	RFB-1134	BNC FEM TO BNC FEM BARREL ADAPTER, N,S,D	N9	
B35 P34 J999 X99	RFB-1134	BNC FEM TO BNC FEM BARREL ADAPTER, N,S,D		
B35 P34 J999 XCP	RFB-1134	BNC FEM TO BNC FEM BARREL ADAPTER, N,S,D		
B35 P96 E999 X99	RFB-1131	BNC T ADAPTER, TRIPLE BNC FEM, N,S,T		
B35 P96 H999 X99	RFB-1131	BNC T ADAPTER, TRIPLE BNC FEM, N,S,T	N9	
B35 P96 J999 X99	RFB-1131	BNC T ADAPTER, TRIPLE BNC FEM, N,S,T		
B35 R50 E999 X99	RFB-1135-I	BNC FEM TO BNC FEM INSUL BULKHD ADAPTER, S,G,D		
B35 R50 H999 X99	RFB-1135-I	BNC FEM TO BNC FEM INSUL BULKHD ADAPTER, S,G,D	N9	
B35 R50 J999 X99	RFB-1135-I	BNC FEM TO BNC FEM INSUL BULKHD ADAPTER, S,G,D		
B35 R50 J999 XCP	RFB-1135-I	BNC FEM TO BNC FEM INSUL BULKHD ADAPTER, S,G,D		
B35 R87 J999 XCP	RFB-1135	BNC FEM TO BNC FEM BLKHD ADAPTER, N,G,D		
B35 R88 H999 X99	RFB-1135	BNC FEM TO BNC FEM BLKHD ADAPTER, N,G,D	N9	
B35 R88 H999 X99	RFB-1135-T	BNC FEM TO BNC FEM BLKHD ADAPTER, O-RING, N,S,T	N9	
B35 R88 J999 X99	RFB-1135	BNC FEM TO BNC FEM BLKHD ADAPTER, N,G,D		
B35 R88 J999 X99	RFB-1135-T	BNC FEM TO BNC FEM BLKHD ADAPTER, O-RING, N,S,T		
B35 R88 J999 XCP	RFB-1135	BNC FEM TO BNC FEM BLKHD ADAPTER, N,G,D		
B35 X20 J999 X99	RFB-1150	BNC MALE TERMINATION 50 Ohm, 1/2 WATT, 1.5 Ghz,, N,G,D		
B35 X25 J999 X99	RFB-1150-1	BNC MALE TERMINATION WITH CHAIN, 50 Ohm, 1/2 WATT, 1.5 Ghz, N,G,D		

B35 Z98 J751 XCP	RFB-1750	BNC 75 OHM MALE TERMINATION, 75 OHM 1/2 WATT N-G-T		
B37 A41 E007 X99	RFB-1708	BNC 75 OHM MALE CRIMP, N,S,D; BELDEN 8281, CBL GRP G		
B37 A41 E007 X99	RFB-1708-1T	BNC 75 OHM MALE CRIMP, S,G,T; FOR BELDEN 8281, CBL GRP G		
B37 A41 EA25 X99	RFB-1707-2	BNC 75 OHM MALE CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
B37 A41 H007 X99	RFB-1707-G	BNC 75 OHM MALE CRIMP PLUG, N,G,T; FOR BELDEN 8281, CBL GRP G		
B37 A41 H022 X99	RFB-1707-S	BNC 75 OHM MALE CRIMP PLUG, N,G,T; RG-179/U, CBL GRP S		
B37 A41 H022 X99	RFB-1106-5	BNC MALE CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, (LG. FERR), CBL GRP B	N9	
B37 A41 HA25 X99	RFB-1707-D	BNC 75 OHM MALE CRIMP, N,G,T; FOR RG-59/U, CBL GRP D		
B37 A41 HA25 X99	RFB-1707-2	BNC 75 OHM MALE CRIMP, N,G,D; FOR RG-59/U, CBL GRP D	N9	
B37 A41 J007 X99	RFB-1708	BNC 75 OHM MALE CRIMP, N,S,D; BELDEN 8281, CBL GRP G		
B37 A41 J007 XCP	RFB-1708	BNC 75 OHM MALE CRIMP, N,S,D; BELDEN 8281, CBL GRP G		
B37 A41 J022 X99	RFB-1106-5	BNC MALE CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, (LG. FERR), CBL GRP B		
B37 A41 JA25 X99	RFB-1707-2	BNC 75 OHM MALE CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
B37 A41 JB25 XCP	RFB-1707-2	BNC 75 OHM MALE CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
B37 A42 HA25 X99	RFB-1707-D	BNC 75 OHM MALE CRIMP, N,G,T; FOR RG-59/U, CBL GRP D		
B37 A48 J025 X99	RFB-1701-D	BNC MALE CLAMP 75 OHM, N,G,T; FOR RG-59/U, CBL GRP D		
B37 A53 J025 X99	RFB-1701-D	BNC MALE CLAMP 75 OHM, N,G,T; FOR RG-59/U, CBL GRP D		
B37 A70 J030X99	RFB-1701-D	BNC MALE CLAMP 75 OHM, N,G,T; FOR RG-59/U, CBL GRP D		
B37 A71 H007X99	RFB-1701-G	BNC 75 OHM MALE SOLDER CLAMP, N,S,T; FOR BELDEN 8281, CBL GRP G		
B37 A71 J028 X99	RFB-1701-D	BNC MALE CLAMP 75 OHM, N,G,T; FOR RG-59/U, CBL GRP D		
B37 A74 HA25 X99	RFB-1707-D	BNC 75 OHM MALE CRIMP, N,G,T; FOR RG-59/U, CBL GRP D		
B37 A98 HA25 X99	RFB-1705	BNC 75 OHM MALE TWIST-ON, N,S,D; FOR RG-59/U, CBL GRP D		
B37 B28 H022 X99	RFB-1710-S	BNC 75 OHM MALE R/A CRIMP PLUG, N,G,D; FOR RG-179/U, CBL GRP S		
B37 B28 HA25 X99	RFB-1710-D	BNC 75 OHM MALE R/A CRIMP PLUG, N,G,T; FOR RG-59/U, CBL GRP D		
B37 B28 HB25 X99	RFB-1710-D	BNC 75 OHM MALE R/A CRIMP PLUG, N,G,T; FOR RG-59/U, CBL GRP D		
B37 E21 H025 X99	RFB-1724-D	BNC 75 OHM FEM CRIMP JACK, N,G,T; FOR RG-59/U, CBL GRP D		
B37 E22 H025 X99	RFB-1720-D*	BNC 75 OHM FEM SOLDER CLAMP, N,G,T, RG-59/U, CBL GRP D		
B37 E43 EA25 X99	RFB-1724	BNC 75 OHM FEM CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
B37 E43 H022 X99	RFB-1724-S	BNC 75 OHM FEM CRIMP JACK, N,G,T; RG-179/U, CBL GRP S		
B37 E43 HA25 X99	RFB-1724-D	BNC 75 OHM FEM CRIMP JACK, N,G,T; FOR RG-59/U, CBL GRP D		
B37 E43 HA25 X99	RFB-1724	BNC 75 OHM FEM CRIMP, N,G,D; FOR RG-59/U, CBL GRP D	N9	
B37 E43 HB25 X99	RFB-1724-D	BNC 75 OHM FEM CRIMP JACK, N,G,T; FOR RG-59/U, CBL GRP D		
B37 E43 HB25 X99	RFB-1724	BNC 75 OHM FEM CRIMP, N,G,D; FOR RG-59/U, CBL GRP D	N9	
B37 E43 JA25 X99	RFB-1724	BNC 75 OHM FEM CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
B37 E43 JB25 X99	RFB-1724	BNC 75 OHM FEM CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
B37 E43 JB25 XCP	RFB-1724	BNC 75 OHM FEM CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
B37 E60 H025 X99	RFB-1720-D*	BNC 75 OHM FEM SOLDER CLAMP, N,G,T, RG-59/U, CBL GRP D		
B37 H07 H025 X99	RFB-1717-D	BNC 75 OHM FEM BULKHEAD CRIMP, REAR MOUNT, D-FLAT, O-RING, N,G,T; FOR RG-59/U, CBL GRP D	N57	
B37 H39 H022 X99	RFB-1717-S	BNC 75 OHM FEM BULKHEAD CRIMP, REAR MOUNT, D-FLAT, O-RING, SOLDER ONLY PIN, N,G,T; FOR RG-179/U, CBL GRP S		
B37 H45 H022 X99	RFB-1717-S	BNC 75 OHM FEM BULKHEAD CRIMP, REAR MOUNT, D-FLAT, O-RING, SOLDER ONLY PIN, N,G,T; FOR RG-179/U, CBL GRP S		
B37 H45 HA25 X99	RFB-1717-D	BNC 75 OHM FEM BULKHEAD CRIMP, REAR MOUNT, D-FLAT, O-RING, N,G,T; FOR RG-59/U, CBL GRP D		
B37 H45 HA25 X99	RFB-1717	BNC 75 OHM FEM CRIMP BULKHEAD, REAR MNT, N,G,D; FOR RG-59/U, CBL GRP D	N9	
B37 H45 HB25 X99	RFB-1717-D	BNC 75 OHM FEM BULKHEAD CRIMP, REAR MOUNT, D-FLAT, O-RING, N,G,T; FOR RG-59/U, CBL GRP D	N57	
B37 H45 HB25 X99	RFB-1717	BNC 75 OHM FEM CRIMP BULKHEAD, REAR MNT, N,G,D; FOR RG-59/U, CBL GRP D	N9	
B37 H45 J022 XCP	RFB-1117-BT	BNC FEM CRIMP BKLHD, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B, MAX. PANEL THICKNESS .20"		
B37 H45 JA25 X99	RFB-1717	BNC 75 OHM FEM CRIMP BULKHEAD, REAR MNT, N,G,D; FOR RG-59/U, CBL GRP D		
B37 H45 JB25 X99	RFB-1717	BNC 75 OHM FEM CRIMP BULKHEAD, REAR MNT, N,G,D; FOR RG-59/U, CBL GRP D		
B37 H45 JB25 X99	RFB-1717	BNC 75 OHM FEM CRIMP BULKHEAD, REAR MNT, N,G,D; FOR RG-59/U, CBL GRP D		
B37 H45 JB25 XCP	RFB-1717	BNC 75 OHM FEM CRIMP BULKHEAD, REAR MNT, N,G,D; FOR RG-59/U, CBL GRP D		
B37 M08 H999 X99	RFB-1716-I	BNC 75 OHM FEM BULKHEAD W/ INSULATED BODY, FRONT MOUNT, N,G,A		
B37 M27 E999 X99	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D		
B37 M27 H999 X99	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D		
B37 M27 J999 X99	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D		
B37 M27 J999 XCP	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D		

B37 M29 E999 X99	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D		
B37 M29 H999 X99	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D		
B37 M29 J999 X99	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D		
B37 M66 H999 X99	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D	N9	
B37 M66 J999 X99	RFB-1716	BNC 75 OHM FEM BLKHD, FRONT MNT, DIECAST ZINC, N,G,D		
B37 P28 H999 X99	RFB-1732	BNC 75 OHM MALE TO BNC FEM R/A ADAPTER, N-G-T		
B37 P31 H999 X99	RFB-1730	BNC 75 OHM MALE TO DOUBLE FEM "T" ADAPTER, N-G-D		
B37 P32 H999 X99	RFB-1733	BNC 75 OHM MALE TO BNC MALE ADAPTER, N-G-T		
B37 P34 H999 X99	RFB-1734	BNC 75 OHM FEM TO BNC FEM ADAPTER, N-G-T		
B37 R87 H999 X99	RFB-1738	BNC 75 OHM MALE TO BNC FEM ADAPTER, N-G-T		
B37 R87 J999 XCP	RFB-1135-T	BNC FEM TO BNC FEM BLKHD ADAPTER, O-RING, N,S,T		
B37 R88 H999 X99	RFB-1735	BNC 75 OHM FEM TO BNC FEM BLKHD ADAPTER, N-G-D		
B65 A61 H022 X99	RSB-4000-B	SMB CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N9	
B65 A61 J022 X99	RSB-4000-B	SMB CRIMP PLUG, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
B65 B37 H022 X99	RSB-4010-B	SMB PLUG, R/A CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B	N9	
B65 B37 J022 X99	RSB-4010-B	SMB PLUG, R/A CRIMP, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
B65 E66 G022 X99	RSB-4050-1B	SMB JACK CRIMP, G, G, T; RG-174/U & RG-316/U, CBL GRP B		
B65 E66 J022 X99	RSB-4050-B	SMB JACK CRIMP, N, G, T; RG-174/U & RG-316/U, CBL GRP B		
B65 H65 H022 X99	RSB-4252-B	SMB JACK, CRIMP BLKHD, REAR MNT, W/ D-FLAT, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
B65 H65 J022 X99	RSB-4252-B	SMB JACK, CRIMP BLKHD, REAR MNT, W/ D-FLAT, N,G,T; FOR RG-174/U & RG-316/U, CBL GRP B		
B65 M08 G999 X99	RSB-4251-1	SMB JACK, BLKHD, REAR MNT, G,G,T		
B65 M08 H999 X99	RSB-4251	SMB JACK, BLKHD, REAR MNT, N,G,T		
B65 M08 J999 X99	RSB-4251	SMB JACK, BLKHD, REAR MNT, N,G,T		
B65 N07 G999 X99	RSB-4350-1	SMB JACK, VERT PCB MNT, G,G,T		
B65 N07 H999 X99	RSB-4350	SMB JACK, VERT PCB MNT, N,G,T	N9	
B65 N07 J999 X99	RSB-4350	SMB JACK, VERT PCB MNT, N,G,T		
B65 N10 G999 X99	RSB-4300-1	SMB JACK, R/A PCB MNT, G,G,T		
B65 N11 G999 X99	RSB-4400-1	SMB PLUG, R/A PCB MNT, G,G,T		
B65 N11 H999 X99	RSB-4300	SMB JACK, R/A PCB MNT, N,G,T	N9	
B65 N11 J999 X99	RSB-4300	SMB JACK, R/A PCB MNT, N,G,T		
B65 N25 G999 X99	RSB-4450-1	SMB PLUG, VERTICAL PCB MNT, G,G,T		
B65 N26 G999 X99	RSB-4450-1	SMB PLUG, VERTICAL PCB MNT, G,G,T		
B65 N27 G999 X99	RSB-4350-1	SMB JACK, VERT PCB MNT, G,G,T		
B65 N30 G999 X99	RSB-4301-1	SMB JACK, R/A BLKHD PCB MNT, G,G,T		
B65 N31 G999 X99	RSB-4400-1	SMB PLUG, R/A PCB MNT, G,G,T		
D75 A03 E999 X99	RFD-1605-2-C	7/16 DIN MALE R/A CRIMP FOR TIMES LMR-200 CABLE, S,S,T; FOR RG-58/U & LMR-200, CBL GRP C,C2		
D75 A03 E999 X99	RFD-1605-2-C1	7/16 DIN MALE CRIMP PLUG, S,S,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
D75 A03 E999 X99	RFD-1605-2-E	7/16 DIN MALE CRIMP, S,S,T; FOR RG-8/U, RG-8/U TYPE & BELDEN 89913, CBL GRP E, I, PL		
D75 G02 E999 R99	RFD-1630-2-E	7/16 DIN FEM CRIMP, S,S,T; FOR RG-8/U, RG-8/U TYPE & BELDEN 89913, CBL GRP E, I, PL		
D75 K01 E99 R99	RFD-1640-2	7/16 DIN FEM 4-HOLE FLANGE W/ SOLDER CUP, S,S,T		
D75 X03 EB04 X99	RFD-1605-2-E	7/16 DIN MALE CRIMP, S,S,T; FOR RG-8/U, RG-8/U TYPE & BELDEN 89913, CBL GRP E, I, PL		
D75 X03 EB04 X99	RFD-1630-2-E	7/16 DIN FEM CRIMP, S,S,T; FOR RG-8/U, RG-8/U TYPE & BELDEN 89913, CBL GRP E, I, PL		
D75 X04 E010 X99	RFD-1605-2-C	7/16 DIN MALE R/A CRIMP FOR TIMES LMR-200 CABLE, S,S,T; FOR RG-58/U & LMR-200, CBL GRP C,C2		
D75 X04 E060 X99	RFD-1605-2-C1	7/16 DIN MALE CRIMP PLUG, S,S,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
GE 501	PT-4000-003	UNIDAPT, MALE N SECTION, S-G-T		
GE 502	PT-4000-009	UNIDAPT, N FEMALE SECTION, S-G-T		
GE 507	PT-4000-004	UNIDAPT, MALE BNC SECTION, S-G-T		
GE 508	PT-4000-010	UNIDAPT, FEMALE BNC SECTION, S-G-T		
GE 511	PT-4000-005	UNIDAPT, MALE TNC SECTION, S-G-T		
GE 512	PT-4000-011	UNIDAPT, FEMALE TNC SECTION, S-G-T		
GE 513	PT-4000-001	UNIDAPT, MALE UHF SECTION, S-G-T		
GE 514	PT-4000-007	UNIDAPT, UHF FEMALE SECTION, S-G-T		

GE 535	PT-4000-006	UNIDAPT, MALE SMA SECTION, S-G-T		
GE 536	PT-4000-012	UNIDAPT, FEMALE SMA SECTION, S-G-T		
K15 K07 J999 C99	RFN-1021	N, FEM, 4-HOLE PANEL MNT, S,G,T		
N15 A14 H001 X99	RFN-1002-1S	N, MALE SOLDER CLAMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	N9
N15 A14 H001 X99	RFN-1002-1N	N, MALE SOLDER CLAMP, N,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N9	
N15 A14 H001 XCP	RFN-1002-1N	N, MALE SOLDER CLAMP, N,G,T; FOR RG-8/U & RG-213/U, CBL GRP E		
N15 A14 J001 X99	RFN-1002-1N	N, MALE SOLDER CLAMP, N,G,T; FOR RG-8/U & RG-213/U, CBL GRP E		
N15 A14 J001 X99	RFN-1002-1S	N, MALE SOLDER CLAMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	
N15 A16 H458 XCP	RFN-1002-1SI	N, MALE SOLDER CLAMP, S,G,T; FOR RG-8/U TYPE, LMR-400 & BELDEN 9913, CBL GRP I	N1	
N15 A54 H010 X99	RFN-1000-1S	N, MALE SOLDER CLAMP, S,G,T; RG-58/U & RG-142/U, CBL GRP C, C1	N1	N9
N15 A54 H010 X99	RFN-1000-N	N, MALE SOLDER CLAMP, N,G,T; RG-58/U & RG-142/U, CBL GRP C, C1		
N15 A54 J010 X99	RFN-1000-N	N, MALE SOLDER CLAMP, N,G,T; RG-58/U & RG-142/U, CBL GRP C, C1		
N15 A54 J010 X99	RFN-1000-1S	N, MALE SOLDER CLAMP, S,G,T; RG-58/U & RG-142/U, CBL GRP C, C1	N1	
N15 A55 H010 XCP	RFN-1000-N	N, MALE SOLDER CLAMP, N,G,T; RG-58/U & RG-142/U, CBL GRP C, C1		
N15 A56 H010 X99	RFN-1000-1S	N, MALE SOLDER CLAMP, S,G,T; RG-58/U & RG-142/U, CBL GRP C, C1	N1	N9
N15 A56 H010 X99	RFN-1000-N	N, MALE SOLDER CLAMP, N,G,T; RG-58/U & RG-142/U, CBL GRP C, C1	N9	
N15 A56 J010 X99	RFN-1000-N	N, MALE SOLDER CLAMP, N,G,T; RG-58/U & RG-142/U, CBL GRP C, C1		
N15 A56 J010 X99	RFN-1000-1S	N, MALE SOLDER CLAMP, S,G,T; RG-58/U & RG-142/U, CBL GRP C, C1	N1	
N15 A61 E001 X99	RFN-1006-3E	N, MALE CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N9	
N15 A61 E004 X99	RFN-1006-3F	N, MALE CRIMP, S,G,T; FOR RG-9/U, CBL GRP F	N9	
N15 A61 H001 X99	RFN-1006-3E	N, MALE CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	N9
N15 A61 H001 XCP	RFN-1006-3E	N, MALE CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	
N15 A61 H004 X99	RFN-1006-3F	N, MALE CRIMP, S,G,T; FOR RG-9/U, CBL GRP F	N1	N9
N15 A61 H004 XCP	RFN-1006-3F	N, MALE CRIMP, S,G,T; FOR RG-9/U, CBL GRP F	N1	
N15 A61 H010 X99	RFN-1005-3C	N, MALE CRIMP, S,G,T; FOR RG-58/U, CBL GRP C	N1	N9
N15 A61 H010 X99	RFN-1005-2N	N, MALE CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N9	
N15 A61 H010 XCP	RFN-1005-2N	N, MALE CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
N15 A61 H060 X99	RFN-1005-3C1	N, MALE CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N1	
N15 A61 H373 XCP	RFN-1006-3E	N, MALE CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	
N15 A61 J001 X99	RFN-1006-3E	N, MALE CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	
N15 A61 J004 X99	RFN-1006-3F	N, MALE CRIMP, S,G,T; FOR RG-9/U, CBL GRP F	N1	
N15 A61 J010 X99	RFN-1005-2N	N, MALE CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
N15 A61 J010 X99	RFN-1005-3C	N, MALE CRIMP, S,G,T; FOR RG-58/U, CBL GRP C	N1	
N15 A61 J060 X99	RFN-1005-3C1	N, MALE CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
N15 A61 J060 X99	RFN-1005-C1	N, MALE CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
N15 B61 E001 X99	RFN-1009-3E	N, MALE R/A CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N9	
N15 B61 E010 X99	RFN-1009-C	N, MALE R/A CRIMP, S,G,T; FOR RG-58/U, CBL GRP C	N9	
N15 B61 E060 X99	RFN-1009-C1	N, MALE R/A CRIMP, S,G,T; RG-142/U & RG-55/U, CBL GRP C1	N9	
N15 B61 H001 X99	RFN-1009-3E	N, MALE R/A CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	N9
N15 B61 H001 XCP	RFN-1009-3E	N, MALE R/A CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	
N15 B61 H010 X99	RFN-1009-C	N, MALE R/A CRIMP, S,G,T; FOR RG-58/U, CBL GRP C	N1	N9
N15 B61 H010 XCP	RFN-1009-C	N, MALE R/A CRIMP, S,G,T; FOR RG-58/U, CBL GRP C	N1	
N15 B61 H060 X99	RFN-1009-C1	N, MALE R/A CRIMP, S,G,T; RG-142/U & RG-55/U, CBL GRP C1	N1	N9
N15 B61 J001 X99	RFN-1009-3E	N, MALE R/A CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	
N15 B61 J010 X99	RFN-1009-C	N, MALE R/A CRIMP, S,G,T; FOR RG-58/U, CBL GRP C	N1	
N15 B61 J060 X99	RFN-1009-C1	N, MALE R/A CRIMP, S,G,T; RG-142/U & RG-55/U, CBL GRP C1	N1	
N15 C20 E999 C99	RFN-1041-1	N, MALE 4-HOLE PANEL MNT, SOLDER CUP, S,G,T	N9	
N15 C20 H999 C99	RFN-1041-1	N, MALE 4-HOLE PANEL MNT, SOLDER CUP, S,G,T		
N15 C20 H999 CCP	RFN-1021-2	N, FEM 4-HOLE PANEL MNT. UG-58A/U, N,G,T		
N15 C20 J999 C99	RFN-1041-1	N, MALE 4-HOLE PANEL MNT, SOLDER CUP, S,G,T		
N15 E21 E001 X99	RFN-1024-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E		
N15 E21 H001 X99	RFN-1024-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E		
N15 E21 H001 XCP	RFN-1024-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E		
N15 E21 J001 X99	RFN-1024-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E		
N15 E30 E 010 X99	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
N15 E30 H010 X99	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
N15 E30 J010 X99	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
N15 E30 J010 XCP	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		

N15 E31 E010 X99	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
N15 E31 H010 X99	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
N15 E31 H010 XCP	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
N15 E31 H010 XCP	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1	N1	
N15 E31 J010 X99	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
N15 E31 J010 XCP	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
N15 E31 J010 XCP	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
N15 E61 E001 X99	RFN-1028	N, FEM CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E		
N15 E61 E001 XCP	RFN-1028	N, FEM CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E		
N15 E61 E01 X99	RFN-1027	N, FEM CRIMP, S,G,T; FOR RG-58/U, CBL GRP C	N9	
N15 E61 E010 XCP	RFN-1027	N, FEM CRIMP, S,G,T; FOR RG-58/U, CBL GRP C		
N15 E61 E060 X99	RFN-1027-C1	N, FEM CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
N15 E61 E060 XCP	RFN-1027-C1	N, FEM CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
N15 E61 H001 X99	RFN-1028	N, FEM CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	N9
N15 E61 H001 XCP	RFN-1028	N, FEM CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	N9
N15 E61 H010 X99	RFN-1027	N, FEM CRIMP, S,G,T; FOR RG-58/U, CBL GRP C	N1	N9
N15 E61 H010 XCP	RFN-1027	N, FEM CRIMP, S,G,T; FOR RG-58/U, CBL GRP C		
N15 E61 H060 X99	RFN-1027-C1	N, FEM CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N1	N9
N15 E61 H060 XCP	RFN-1027-C1	N, FEM CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
N15 E61 H060 XCP	RFN-1027-C1	N, FEM CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N1	N9
N15 E61 J001 X99	RFN-1028	N, FEM CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	
N15 E61 J001 XCP	RFN-1028	N, FEM CRIMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E		
N15 E61 J010 X99	RFN-1027	N, FEM CRIMP, S,G,T; FOR RG-58/U, CBL GRP C		
N15 E61 J010 XCP	RFN-1027	N, FEM CRIMP, S,G,T; FOR RG-58/U, CBL GRP C		
N15 E61 J060 X99	RFN-1027-C1	N, FEM CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1	N1	
N15 E61 J060 XCP	RFN-1027-C1	N, FEM CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
N15 E61 J060 XCP	RFN-1027-C1	N, FEM CRIMP, S,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
N15 G30 E010 XCP	RFN-1025-1	N, FEM SOLDER CLAMP, S,G,T; FOR RG-142/U & RG-58/U, CBL GRP C,C1		
N15 G57 E010C99	RFN-1021-6	N, FEM, SOLDER CLAMP 4-HOLE PANEL MNT, S,G,T; FOR RG-58/U & RG-142/U, CBL GRP C, C1	N9	
N15 G57 H010C99	RFN-1021-6	N, FEM, SOLDER CLAMP 4-HOLE PANEL MNT, S,G,T; FOR RG-58/U & RG-142/U, CBL GRP C, C1	N1	N9
N15 G57 J010C99	RFN-1021-6	N, FEM, SOLDER CLAMP 4-HOLE PANEL MNT, S,G,T; FOR RG-58/U & RG-142/U, CBL GRP C, C1	N1	
N15 H61 H010 X99	RFN-1022-8-C	N, FEM CRIMP, REAR MNT BLKHD, N,G,T; FOR RG-58/U, CBL GRP C		
N15 H61 H060 X99	RFN-1022-8-C1	N, FEM CRIMP, REAR MNT BLKHD, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
N15 H61 J010 X99	RFN-1022-8-C	N, FEM CRIMP, REAR MNT BLKHD, N,G,T; FOR RG-58/U, CBL GRP C		
N15 H61 J060 X99	RFN-1022-8-C1	N, FEM CRIMP, REAR MNT BLKHD, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
N15 K07 E999 C99	RFN-1021	N, FEM, 4-HOLE PANEL MNT, S,G,T		
N15 K07 H999 CCP	RFN-1022-1	N, FEM, BLKHD, DOUBLE 'D' FLAT, FRONT MNT, S,G,T	N1	
N15 K07 J999 C99	RFN-1021-2	N, FEM 4-HOLE PANEL MNT. UG-58A/U, N,G,T		
N15 K42 E999 C99	RFN-1021	N, FEM, 4-HOLE PANEL MNT, S,G,T		
N15 K42 E999 C99	RFN-1021-2	N, FEM 4-HOLE PANEL MNT. UG-58A/U, N,G,T		
N15 K42 J999 C99	RFN-1021-2	N, FEM 4-HOLE PANEL MNT. UG-58A/U, N,G,T		
N15 K45 H999 C99	RFN-1021-14	N, FEM 4-HOLE PANEL MNT.W/ SLOTTED TERMINAL, N-G-T		
N15 K45 J999 C99	RFN-1021-14	N, FEM 4-HOLE PANEL MNT.W/ SLOTTED TERMINAL, N-G-T		
N15 M28 H999 X99	RFN-1022-5	N, FEM BLKHD, FRONT MNT, BNC THREADS, DBL D-FLAT, N,G,T	N9	
N15 M28 H999 XCP	RFN-1022-5	N, FEM BLKHD, FRONT MNT, BNC THREADS, DBL D-FLAT, N,G,T		
N15 M28 J999 X99	RFN-1022-5	N, FEM BLKHD, FRONT MNT, BNC THREADS, DBL D-FLAT, N,G,T		
N15 M28 J999 XCP	RFN-1022-5	N, FEM BLKHD, FRONT MNT, BNC THREADS, DBL D-FLAT, N,G,T		
N15 M33 E999 X99	RFN-1022-1	N, FEM, BLKHD, DOUBLE 'D' FLAT, FRONT MNT, S,G,T	N9	
N15 M33 E999 XCP	RFN-1022-1	N, FEM, BLKHD, DOUBLE 'D' FLAT, FRONT MNT, S,G,T		
N15 M33 H999 X99	RFN-1022-1	N, FEM, BLKHD, DOUBLE 'D' FLAT, FRONT MNT, S,G,T	N1	N9
N15 M33 H999 XCP	RFN-1022-1	N, FEM, BLKHD, DOUBLE 'D' FLAT, FRONT MNT, S,G,T	N1	
N15 M33 J999 X99	RFN-1022-1	N, FEM, BLKHD, DOUBLE 'D' FLAT, FRONT MNT, S,G,T	N1	
N15 M33 J999 XCP	RFN-1022-1	N, FEM, BLKHD, DOUBLE 'D' FLAT, FRONT MNT, S,G,T		
N15 N45 E999 C99	RFN-1021-14	N, FEM 4-HOLE PANEL MNT.W/ SLOTTED TERMINAL, N-G-T		
N15 P08 E999 X99	RFN-1010-1	N T ADAPTER-2 FEM, 1 MALE, S,G,T	N9	
N15 P08 E999 X99	RFN-1017	N T ADAPTER, MALE- FEM-FEM, S,G,T	N9	

N15 P08 E999 XCP	RFN-1010-1	N T ADAPTER-2 FEM, 1 MALE, S,G,T		
N15 P08 E999 XCP	RFN-1017	N T ADAPTER, MALE- FEM-FEM, S,G,T		
N15 P08 H999 X99	RFN-1010-1	N T ADAPTER-2 FEM, 1 MALE, S,G,T	N1	N9
N15 P08 H999 X99	RFN-1017	N T ADAPTER, MALE- FEM-FEM, S,G,T	N1	N9
N15 P08 H999 XCP	RFN-1017	N T ADAPTER, MALE- FEM-FEM, S,G,T		
N15 P08 H999 XCP	RFN-1010-1	N T ADAPTER-2 FEM, 1 MALE, S,G,T	N1	
N15 P08 J999 X99	RFN-1010-1	N T ADAPTER-2 FEM, 1 MALE, S,G,T	N1	N9
N15 P08 J999 X99	RFN-1017	N T ADAPTER, MALE- FEM-FEM, S,G,T	N1	
N15 P08 J999 XCP	RFN-1010-1	N T ADAPTER-2 FEM, 1 MALE, S,G,T		
N15 P08 J999 XCP	RFN-1017	N T ADAPTER, MALE- FEM-FEM, S,G,T		
N15 P09 E999 X99	RFN-1012-1	N FEM TO N MALE R/A ADAPTER, S,G,T	N9	
N15 P09 E999 XCP	RFN-1012-1	N FEM TO N MALE R/A ADAPTER, S,G,T		
N15 P09 H999 X99	RFN-1012-1	N FEM TO N MALE R/A ADAPTER, S,G,T	N1	N9
N15 P09 H999 XCP	RFN-1012-1	N FEM TO N MALE R/A ADAPTER, S,G,T	N1	
N15 P09 J999 X99	RFN-1012-1	N FEM TO N MALE R/A ADAPTER, S,G,T	N1	
N15 P09 J999 XCP	RFN-1012-1	N FEM TO N MALE R/A ADAPTER, S,G,T		
N15 P10 E999 X99	RFN-1014-1	N MALE TO N MALE ADAPTER, S,G,T	N9	
N15 P10 E999 XCP	RFN-1014-1	N MALE TO N MALE ADAPTER, S,G,T		
N15 P10 H999 X99	RFN-1014-1	N MALE TO N MALE ADAPTER, S,G,T	N1	N9
N15 P10 H999 XCP	RFN-1014-1	N MALE TO N MALE ADAPTER, S,G,T	N1	
N15 P10 J999 X99	RFN-1014-1	N MALE TO N MALE ADAPTER, S,G,T	N1	
N15 P10 J999 XCP	RFN-1014-1	N MALE TO N MALE ADAPTER, S,G,T		
N15 P12 E999 X99	RFN-1013-1	N FEM TO N FEM BARREL ADAPTER, S,G,T	N9	
N15 P12 H999 X99	RFN-1013-1	N FEM TO N FEM BARREL ADAPTER, S,G,T	N1	N9
N15 P12 H999 XCP	RFN-1013-1	N FEM TO N FEM BARREL ADAPTER, S,G,T	N1	
N15 P12 J999 X99	RFN-1013-1	N FEM TO N FEM BARREL ADAPTER, S,G,T	N1	
N15 P29 E999 X99	RFN-1011-1	N T ADAPTER-3 FEM, S,G,T	N9	
N15 P29 E999 XCP	RFN-1011-1	N T ADAPTER-3 FEM, S,G,T		
N15 P29 H999 X99	RFN-1011-1	N T ADAPTER-3 FEM, S,G,T	N1	N9
N15 P29 H999 XCP	RFN-1011-1	N T ADAPTER-3 FEM, S,G,T	N1	
N15 P29 J999 X99	RFN-1011-1	N T ADAPTER-3 FEM, S,G,T	N1	
N15 P29 J999 XCP	RFN-1011-1	N T ADAPTER-3 FEM, S,G,T		
N15 R56 9999 XCP	RFN-1023	N FEM TO N FEM FRONT MNT BLKHD ADAPTER, S,S,T		
N15 R56 E999 X99	RFN-1023	N FEM TO N FEM FRONT MNT BLKHD ADAPTER, S,S,T		
N15 R56 E999 XCP	RFN-1023	N FEM TO N FEM FRONT MNT BLKHD ADAPTER, S,S,T		
N15 R56 H999 X99	RFN-1023	N FEM TO N FEM FRONT MNT BLKHD ADAPTER, S,S,T	N1	N9
N15 R56 H999 XCP	RFN-1023	N FEM TO N FEM FRONT MNT BLKHD ADAPTER, S,S,T	N1	
N15 R56 J999 X99	RFN-1023	N FEM TO N FEM FRONT MNT BLKHD ADAPTER, S,S,T	N1	
N17 A01 H001 X99	RFN-1002-1S	N, MALE SOLDER CLAMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	N9
N17 A01 H001 X99	RFN-1002-1N	N, MALE SOLDER CLAMP, N,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N9	
N17 A01 J001 X99	RFN-1002-1N	N, MALE SOLDER CLAMP, N,G,T; FOR RG-8/U & RG-213/U, CBL GRP E		
N17 A01 J001 X99	RFN-1002-1S	N, MALE SOLDER CLAMP, S,G,T; FOR RG-8/U & RG-213/U, CBL GRP E	N1	
N17 A55 E025 X99	RFN-1904-1S	N, 75 OHM MALE SOLDER CLAMP, S,G,T; RG-59/U, CBL GRP D		
N17 A55 H025 X99	RFN-1904-1N	N, 75 OHM MALE SOLDER CLAMP, N,G,T; RG-59/U, CBL GRP D		
N17 A55 H025 X99	RFN-1904-1S	N, 75 OHM MALE SOLDER CLAMP, S,G,T; RG-59/U, CBL GRP D		
N17 A55 H025 XCP	RFN-1904-1N	N, 75 OHM MALE SOLDER CLAMP, N,G,T; RG-59/U, CBL GRP D		
N17 A55 J02 X99	RFN-1904-1S	N, 75 OHM MALE SOLDER CLAMP, S,G,T; RG-59/U, CBL GRP D		
N17 A55 J025 X99	RFN-1904-1N	N, 75 OHM MALE SOLDER CLAMP, N,G,T; RG-59/U, CBL GRP D		
N17 A55 J025 XCP	RFN-1904-1N	N, 75 OHM MALE SOLDER CLAMP, N,G,T; RG-59/U, CBL GRP D		
STI02405-10	PT-4000-013	UNIDAPT, UNIVERAL CENTER, SECTION ADAPTER , S-G-T		
T35 A01 H010 X99	RFT-1200	TNC, MALE SOLDER CLAMP, N,G,T; FOR RG-142/U & RG58/U, CBL GRP C,C1	N9	
T35 A01 H022 X99	RFT-1200-1B*	TNC, MALE SOLDER CLAMP, FOR RG-174/U, CBL GRP B, N,G,T	N9	
T35 A01 J010 X99	RFT-1200	TNC, MALE SOLDER CLAMP, N,G,T; FOR RG-142/U & RG58/U, CBL GRP C,C1		
T35 A01 J022 X99	RFT-1200-1B*	TNC, MALE SOLDER CLAMP, FOR RG-174/U, CBL GRP B, N,G,T		
T35 A11 H010 X99	RFT-1200	TNC, MALE SOLDER CLAMP, N,G,T; FOR RG-142/U & RG58/U, CBL GRP C,C1	N9	
T35 A11 J010 X99	RFT-1200	TNC, MALE SOLDER CLAMP, N,G,T; FOR RG-142/U & RG58/U, CBL GRP C,C1		
T35 A41 H010 X99	RFT-1202-2	TNC, MALE CRIMP, N,G,D; FOR RG-58/U, CBL GRP C	N9	
T35 A41 H010 X99	RFT-1202-2T	TNC, MALE CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N9	

T35 A41 H022 X99	RFT-1202-3	TNC, MALE CRIMP, N,G,D; RG-174/U & RG-316/U, CBL GRP B	N9	
T35 A41 H060 X99	RFT-1202-C1	TNC, MALE CRIMP, N,G,D; RG-142/U & RG-55/U, CBL GRP C1	N9	
T35 A41 J010 X99	RFT-1202-2	TNC, MALE CRIMP, N,G,D; RG-58/U, CBL GRP C		
T35 A41 J010 X99	RFT-1202-2T	TNC, MALE CRIMP, N,G,T; RG-58/U, CBL GRP C		
T35 A41 J010 XCP	RFT-1202-2T	TNC, MALE CRIMP, N,G,T; RG-58/U, CBL GRP C		
T35 A41 J022 X99	RFT-1202-3	TNC, MALE CRIMP, N,G,D; RG-174/U & RG-316/U, CBL GRP B		
T35 A41 J060 X99	RFT-1202-C1	TNC, MALE CRIMP, N,G,D; RG-142/U & RG-55/U, CBL GRP C1		
T35 A70 J010 XCP	RFT-1200	TNC, MALE SOLDER CLAMP, N,G,T; FOR RG-142/U & RG58/U, CBL GRP C,C1	N3	
T35 B28 H010 X99	RFT-1218	TNC, MALE R/A CRIMP, N,G,T; FOR RG-58/U, CBL GRP C	N9	
T35 B28 H060 X99	RFT-1218-C1	TNC, MALE R/A CRIMP, N,G,T; RG-142/U & RG-55/U, CBL GRP C1	N9	
T35 B28 J010 X99	RFT-1218	TNC, MALE R/A CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
T35 B28 J010 XCP	RFT-1218	TNC, MALE R/A CRIMP, N,G,T; FOR RG-58/U, CBL GRP C		
T35 B28 J060 X99	RFT-1218-C1	TNC, MALE R/A CRIMP, N,G,T; FOR RG-142/U & RG-55/U, CBL GRP C1		
T35 E43 H010 X99	RFT-1216-1	TNC, FEM CRIMP, N,G,D; FOR RG-58/U, CBL GRP C	N9	
T35 E43 J010 X99	RFT-1216-1	TNC, FEM CRIMP, N,G,D; FOR RG-58/U, CBL GRP C		
T35 H45 H010 X99	RFT-1212	TNC, FEM CRIMP BLKHD, N,G,D; FOR RG-58/U, CBL GRP C	N9	
T35 H45 H060 X99	RFT-1212-C1	TNC, FEM BLKHD CRIMP, N,G,D; FOR RG-142/U & RG-55/U, CBL GRP C1	N9	
T35 H45 J010 X99	RFT-1212	TNC, FEM CRIMP BLKHD, N,G,D; FOR RG-58/U, CBL GRP C		
T35 H45 J010 XCP	RFT-1212	TNC, FEM CRIMP BLKHD, N,G,D; FOR RG-58/U, CBL GRP C		
T35 H45 J060 X99	RFT-1212-C1	TNC, FEM BLKHD CRIMP, N,G,D; FOR RG-142/U & RG-55/U, CBL GRP C1		
T35 K07 H999 H99	RFT-1211-1	TNC, FEM FRONT MNT BLKHD, D-FLAT, N,G,T	N9	
T35 K07 J999 H99	RFT-1211-1	TNC, FEM FRONT MNT BLKHD, D-FLAT, N,G,T		
T35 K07 J999 HCP	RFT-1210	TNC, FEM 4-HOLE PANEL MNT, N,G,T		
T35 M27 J999 XCP	RFT-1211-1	TNC, FEM FRONT MNT BLKHD, D-FLAT, N,G,T		
T35 N83 H999 099	RFT-1209-1B	TNC, FEM VERT LOW PRO PCB MNT, BLACK VALOX, A,G,P; POST LEG; NO HARDWARE	N9	
T35 N83 H999 999	RFT-1209-1W	TNC, FEM VERT LOW PRO PCB MNT, WHITE VALOX, A,G,P; POST LEG; W/ HARDWARE	N9	
T35 N83 J999 099	RFT-1209-1B-04	TNC, FEM VERT LOW PRO PCB MNT, BLACK VALOX, A,G,P; W/ NO HARDWARE		
T35 N83 J999 999	RFT-1209-1W-04	TNC, FEM VERT LOW PRO PCB MNT, WHITE VALOX, A,G,P; POST LEGSW/ NO HARDWARE		
T35 N88 H999 099	RFT-1209-B	TNC, FEM R/A LOW PRFILE PCB MNT, BLACK VALOX, A,G,P; POST LEG; W/ HARDWARE	N9	
T35 N88 H999 999	RFT-1209-W	TNC, FEM R/A LOW PRFILE PCB MNT, WHITE VALOX, A,G,P; POST LEG; W/ HARDWARE	N9	
T35 N88 J999 099	RFT-1209-B-04	TNC, FEM R/A LOW PRFILE PCB MNT, BLACK VALOX, A,G,P; W/ NO HARDWARE		
T35 N88 J999 999	RFT-1209-W-04	TNC, FEM R/A LOW PRFILE PCB MNT, WHITE VALOX, A,G,P; W/ NO HARDWARE		
T35 P28 H999 X99	RFT-1227	TNC FEM TO TNC MALE R/A ADAPTER, N,G,T	N9	
T35 P28 J999 X99	RFT-1227	TNC FEM TO TNC MALE R/A ADAPTER, N,G,T		
T35 P31 H999 X99	RFT-1228	TNC, T ADAPTER 1 MALE-2 FEM, N,G,T	N9	
T35 P31 J999 X99	RFT-1228	TNC, T ADAPTER 1 MALE-2 FEM, N,G,T		
T35 P32 H999 X99	RFT-1224	TNC MALE TO TNC MALE BARREL ADAPTER., N,S,T	N9	
T35 P32 J999 X99	RFT-1224	TNC MALE TO TNC MALE BARREL ADAPTER., N,S,T		
T35 P34 H999 X99	RFT-1225	TNC FEM TO FEM BARREL ADAPTER, N,G,T	N9	
T35 P34 J999 X99	RFT-1225	TNC FEM TO FEM BARREL ADAPTER, N,G,T		
T35 R53 H999 X99	RFT-1226	TNC FEM TO TNC FEM DBL BLKD, N,G,T	N9	
T35 R53 J999 X99	RFT-1226	TNC FEM TO TNC FEM DBL BLKD, N,G,T		
T35 R54 H999 X99	RFT-1226	TNC FEM TO TNC FEM DBL BLKD, N,G,T	N9	
T35 R54 J999 X99	RFT-1226	TNC FEM TO TNC FEM DBL BLKD, N,G,T		
T37 A41 HA25 X99	RFT-1803-1	TNC, 75 OHM MALE CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		
T37 A48 H025 X99	RFT-1801*	TNC, MALE CLAMP FOR RG-59/U, N,S,T		
T37 A48 H025 X99	RFT-1200-C1*	TNC MALE SOLDER CLAMP FOR FUGIKURA, 5D-FB, N,G,T	N9	
T37 A48 J025 X99	RFT-1200-C1*	TNC MALE SOLDER CLAMP FOR FUGIKURA, 5D-FB, N,G,T		
T37 H45 HA25 X99	RFT-1813	TNC, 75 OHM FEM CRIMP BLKHD, N,G,D; RG-59/U, CBL GRP D		
T37 H45 JB25 X99	RFT-1813	TNC, 75 OHM FEM CRIMP BLKHD, N,G,D; RG-59/U, CBL GRP D		
T37 H45 JB25 XCP	RFT-1813	TNC, 75 OHM FEM CRIMP BLKHD, N,G,D; RG-59/U, CBL GRP D		
T37 H51 HA25 X99	RFT-1813	TNC, 75 OHM FEM CRIMP BLKHD, N,G,D; RG-59/U, CBL GRP D		
T37 H51 HB25 X99	RFT-1813	TNC, 75 OHM FEM CRIMP BLKHD, N,G,D; RG-59/U, CBL GRP D		
T37-A41-JB25-XCP	RFT-1803-1	TNC, 75 OHM MALE CRIMP, N,G,D; FOR RG-59/U, CBL GRP D		

U40 A01 H004 X99	RFU-500	UHF, MALE SOLDER PLUG, S-S-DAP; FOR RG-8/U, CBL-C,D,E,F,P,X, PL-259		
U40 A01 H004 XCP	RFU-500	UHF, MALE SOLDER PLUG, S-S-DAP; FOR RG-8/U, CBL-C,D,E,F,P,X, PL-259		
U40 K03 H999 CCP	RFU-521	UHF, FEM 4-HOLE PANEL MNT, SO-239, N,S,B		
U40 M10 H999 XCP	RFU-523	UHF, FEM FRONT MNT BLKHD, D-FLAT, SO-239-FM, N,S,B		
U40 P06 H999 X99	RFU-536	UHF FEM TO UHF FEM BARREL ADAPTER, N,S,D		
U40 P06 H999 XCP	RFU-536	UHF FEM TO UHF FEM BARREL ADAPTER, N,S,D		
U40 P42 H999 X99	RFU-533	UHF T ADAPTER, DOUBLE FEM,1 MALE, N,S,D		
U40 P42 H999 XCP	RFU-533	UHF T ADAPTER, DOUBLE FEM,1 MALE, N,S,D		
U40 R77 H999 X99	RFU-537	UHF FEM TO UHF FEM BLKHD ADAPTER, N,S,D		
U40 R77 H999 XCP	RFU-537	UHF FEM TO UHF FEM BLKHD ADAPTER, N,S,D		
U40 X08 H999 X99	RFU-530	REDUCER, USE W / RFU-500, RG-58/U, NICKEL		
U40 X08 H999 XCP	RFU-530	REDUCER, USE W / RFU-500, RG-58/U, NICKEL		
U40 X09 H999 X99	RFU-531	REDUCER, USE W / RFU-500, RG-59/U, NICKEL,		
U40 X09 H999 XCP	RFU-531	REDUCER, USE W / RFU-500, RG-59/U, NICKEL,		

This cross-reference is offered as a general selection guide only. Variations of style occur between connector manufacturers' product lines and within each company's line. Specifications on any connector are subject to change without notice. We therefore ask that before making any part substitution, you carefully verify current specifications from the manufacturers for those parts.

NOTES

RFI connector has silver plating, this connector has nickel.	N1	
RFI connector has PTFE dielectric, this connector has Delrin (Acetal).	N2	
RFI contact is silver, this contact is gold.	N3	
RFI connector has Delrin (Acetal) dielectric, this connector has PTFE.	N4	
RFI contact is silver, this contact is nickel. RFI contact is gold, this contact is nickel.	N5	
RFI contact is gold, this contact is nickel.	N6	
RFI connector has Polypropylene dielectric, this connector has PTFE.	N7	
RFI connector has nickel plating, this connector has silver.	N8	
RFI contact is gold, this contact is silver.	N9	
RFI connector is nickel plated brass, this connector is Passivated Stainless-Steel.	N10	
This connector is made to accommodate both RG-8/U and RG-9/U. Ferrules and clamps may fit loosely.	N11	
RFI connector has nickel plating, this connector has gold.	N12	
Solder dipped legs and terminal on this part.	N13	
The RFI connector is machined brass, this connector is zinc diecast.	N14	
RFI connector is diecast, this connector is machined brass.	N15	
This RFI connector has nickel plated finish.	N16	
This flange has #3-56 tapped holes; the RFI flange does not.	N17	
This connector requires C1 Ferrule.	N18	
RFI connector ships w/ hardware; this connector does not.	N19	
RFI connector is high-profile style, this connector is low-profile style.	N20	